



Installation, Operation, and Maintenance

Multi Variable Air Conditioners

Ducted Type Indoor Unit

Model Number:

TRN-ID72HA1

TRN-ID96HA1

⚠ SAFETY WARNING

Only qualified personnel should install and service the equipment. The installation, starting up, and servicing of heating, ventilating, and air-conditioning equipment can be hazardous and requires specific knowledge and training. Improperly installed, adjusted or altered equipment by an unqualified person could result in death or serious injury. When working on the equipment, observe all precautions in the literature and on the tags, stickers, and labels that are attached to the equipment.

⚠ AVERTISSEMENT DE SÉCURITÉ

Seul le personnel qualifié doit installer et procéder à l'entretien des équipements. L'installation, le démarrage et la réparation des équipements de chauffage, de ventilation et de climatisation peuvent être dangereux et nécessitent une formation et des connaissances spécifiques. Un équipement mal installé, réglé ou modifié par un individu non qualifié peut entraîner des blessures graves, voire mortelles. Lors de toute intervention sur l'équipement, respectez toutes les précautions figurant dans la documentation et sur les étiquettes et autocollants fixés à l'équipement.

Preface

For correct installation and operation, please read all instructions carefully. Before reading the instructions, please be aware of the following items:


 DANGER	This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.
 WARNING	This mark indicates procedures which, if improperly performed, might lead to the death or serious injury of the user.
 CAUTION	This mark indicates procedures which, if improperly performed, might possibly result in personal harm to the user, or damage to property.
NOTICE	NOTICE is used to address practices not related to personal injury.

 WARNING	
(1)	Instructions for installation and use of this product are provided by the manufacturer.
(2)	Installation must be performed in accordance with the requirements of NEC and CEC by authorized personnel only.
(3)	For the safe operation of this unit, please read and follow the instructions carefully.
(4)	During operation, total capacity of indoor units should not exceed the total capacity of outdoor units. Otherwise, poor effect of cooling or heating may result.
(5)	Direct operators or maintainers should well keep this manual.
(6)	If this unit fails to operate normally, please contact our service center as soon as possible and provide the following information: 1) Content on the nameplate (model number, cooling capacity, production code, ex-factory date). 2) Malfunction details (before and after the malfunction occurs).
(7)	Each unit has been strictly tested and proved to be qualified before ex-factory. In order to prevent units from being damaged or operating normally because of improper disassembly, please do not disassemble the unit by yourself. If you need to disassemble and check units, please contact our service center. We will send specialists to guide the disassembly.
(8)	Under the standby status, the unit will consume a little power for ensuring reliability of complete unit, maintaining normal communication and preheating refrigerant. When the unit won't be used for a long time, cut off the power of the complete unit. However, please preheat it when operating the unit next time.

User Notice

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

DISPOSAL: Do not dispose this product as unsorted municipal waste. Collection of such waste separately for special treatment is necessary.

	Correct Disposal of this product This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.
---	--

Exception Clauses
Manufacturer will bear no responsibilities when personal injury or property loss is caused by the following reasons:
(1) Damage the product due to improper use or misuse of the product;
(2) Alter, change, maintain or use the product with other equipment without abiding by the instruction manual of manufacturer;
(3) After verification, the defect of product is directly caused by corrosive gas;
(4) After verification, defects are due to improper operation during transportation of product;
(5) Operate, repair, maintain the unit without abiding by instruction manual or related regulations;
(6) After verification, the problem or dispute is caused by the quality specification or performance of parts and components that produced by other manufacturers;
(7) The damage is caused by natural calamities, bad using environment or force majeure.

Contents

1 Safety Precautions	1
2 Product Introduction	2
2.1 Names of Key Components	2
2.2 Rated Working Condition	2
3 Preparations for Installation	2
3.1 Standard Fittings	2
3.2 Location for Installation	3
3.3 Requirements for Communication Line	4
3.4 Wiring Requirements.....	5
4 Installation Instructions	5
4.1 Installation of Indoor Unit.....	6
4.2 Refrigerant Pipe Connection	8
4.3 Drainage Pipe Installation and Drainage System Testing	8
4.4 Installation of Air Duct	11
4.5 Installation of Wired Controller	12
4.6 External Static Pressure Settings	13
5 Wiring Work	14
5.1 Connection of Wire and Patch Board Terminal	14
5.2 Power Cord Connection	15
5.3 Connection of Communication Wire between Indoor Unit and Outdoor Unit (or indoor unit).....	16
5.4 Connect Communication Wire of Wired Controller	16
5.5 Illuminate for Connection of Wired Controller and Indoor Units Network	17
6 Routine Maintenance.....	19
6.1 Cleaning of Filter	19
6.2 Maintenance before the Seasonal Use.....	19
6.3 Maintenance after the Seasonal Use.....	19
7 The Table of Error Codes for Indoor Unit	20
8 Troubleshooting	20

1 Safety Precautions

WARNING

- (1) This product can't be installed at corrosive, inflammable or explosive environment or the place with special requirements, such as kitchen. Otherwise, it will affect the normal operation or shorten the service life of the unit, or even cause fire hazard or serious injury. As for above special places, please adopt special air conditioner with anti-corrosive or anti-explosion function.
- (2) Follow this instruction to complete the installation work. Please carefully read this manual before unit startup and service.
- (3) Wire size of power cord should be large enough. The damaged power cord and connection wire should be replaced by exclusive cable.
- (4) After connecting the power cord, please fix the electric box cover properly in order to avoid accident.
- (5) Never fail to comply with the nitrogen charge requirements. Charge nitrogen when welding pipes.
- (6) Never short-circuit or cancel the pressure switch to prevent unit damage.
- (7) Please firstly connect the wired controller before energization, otherwise wired controller cannot be used.
- (8) Before using the unit, please check if the piping and wiring are correct to avoid water leakage, refrigerant leakage, electric shock, or fire etc.
- (9) Do not insert fingers or objects into air outlet/inlet grille.
- (10) Open the door and window and keep good ventilation in the room to avoid oxygen deficit when the gas/oil supplied heating equipment is used.
- (11) Never start up or shut off the air conditioner by means of directly plug or unplug the power cord.
- (12) Turn off the unit after it runs at least five minutes; otherwise it will influence oil return of the compressor.
- (13) Do not allow children operate this unit.
- (14) Do not operate this unit with wet hands.
- (15) Turn off the unit or cut off the power supply before cleaning the unit, otherwise electric shock or injury may happen.
- (16) Never spray or flush water towards unit, otherwise malfunction or electric shock may happen.
- (17) Do not expose the unit to the moist or corrosive circumstances.
- (18) Under cooling mode, please don't set the room temperature too low.
- (19) User is not allowed to repair the unit. Fault service may cause electric shock or fire accidents. Please contact Gree appointed service center for help.
- (20) Before installation, please check if the power supply is in accordance with the requirements specified on the nameplate. And also take care of the power safety.
- (21) Installation should be conducted by dealer or qualified personnel. Please do not attempt to install the unit by yourself. Improper handling may result in water leakage, electric shock or fire disaster etc.
- (22) Be sure to use the exclusive accessory and part to prevent the water leakage, electric shock and fire accidents.
- (23) Make sure the unit can be earthed properly and soundly after plugging into the socket so as to avoid electric shock. Please do not connect the ground wire to gas pipe, water pipe, lightning rod or telephone line.
- (24) Electrify the unit 8 hours before operation. Please switch on for 8 hours before operation. Do not cut off the power when 24 hours short-time halting (to protect the compressor).
- (25) If refrigerant leakage happens during installation, please ventilate immediately. Poisonous gas will emerge if the refrigerant gas meets fire.
- (26) Volatile liquid, such as diluent or gas will damage the unit appearance. Only use soft cloth with a little neutral detergent to clean the outer casing of unit.
- (27) If anything abnormal happens (such as burning smell), please power off the unit and cut off the main power supply, and then immediately contact Gree appointed service center. If abnormality keeps going, the unit might be damaged and lead to electric shock or fire.

⚠ WARNING
(28) HVAC systems may experience operational disruptions due to electromagnetic interference (EMI), potentially affecting medical devices and broadcast signal transmissions. Conversely, variable-frequency drives (VFDs), dedicated generators, high-frequency medical devices, and radio communication equipment may also interfere with HVAC system operation.
(29) The mounting bracket shall remain structurally sound throughout its service life. Any degradation must be repaired immediately; failure to do so may cause equipment detachment, resulting in personal injury or property damage.
(30) Handle equipment with care during transportation. Team handling is required; use appropriate handling equipment. Never grasp the packaging straps; wear safety gloves during unpacking and handling to prevent injury.
(31) Do not turn off the power immediately after stopping operation. Always wait for at least 5 minutes before turning off the power. Otherwise, it may cause water leakage or equipment damage.
(32) Consult local building codes and National Electrical Code (NEC) for special requirements. Recognize safety information. In Canada, refer to the current editions of the Canadian Electrical Code CSA C22.1.

2 Product Introduction

2.1 Names of Key Components




Fig.2.1

2.2 Rated Working Condition

— / —	Indoor Side Condition		Outdoor Side Condition	
	Dry Bulb Temp ℃ (°F)	Wet Bulb Temp ℃ (°F)	Dry Bulb Temp ℃ (°F)	Wet Bulb Temp ℃ (°F)
Rated Cooling	26.7(80.0)	19.4(67.0)	35(95.0)	23.9(75.0)
Rated Heating	21.1(70.0)	15.6(60.0)	8.3(47.0)	6.1(43.0)

3 Preparations for Installation


NOTICE

Product graphics are only for reference. Please refer to actual products. Unspecified measure unit is mm (inch).

3.1 Standard Fittings

Please use the supplied standard fittings listed below as instructed.

No.	Name	Appearance	Q'ty	Usage
1	Wired Controller		1	To control the indoor unit
2	Special Nut		1	To be used for connecting the refrigerant pipe
3	Insulation		1	To insulate the gas pipe

No.	Name	Appearance	Q'ty	Usage
4	Insulation		1	To insulate the liquid pipe
5	Fastener		8	To fasten the sponge
6	Hanger	 or 	4	To fix the indoor unit
7	M8 Nut (M8×6.8)		8	To fix the hook on the cabinet of the unit.
8	M8 Washer (Spring Washer M8×2.1)		8	To fix the hook on the cabinet of the unit.
9	M8 Washer (M8×Φ16×1.5)		8	To fix the hook on the cabinet of the unit.
10	paper pattern for installation		1	Locate the drill hole on ceiling

3.2 Location for Installation

- (1) The appliance shall not be installed in the laundry.
- (2) The top holder must be strong enough to support unit's weight.
- (3) Drain pipe can drain water out easily.
- (4) There is no obstacle at inlet or outlet. Please ensure good air circulation.
- (5) In order to make sure the space for maintenance, please install the indoor unit according to the dimension described below.
- (6) Keep the unit away from heating source, inflammable gas or smoke.
- (7) This is a concealed ceiling type unit.
- (8) Indoor unit, outdoor unit, power cord and electric wire should stay at least 1m (39-3/8inch) from the TV set and radio. Otherwise, these electrical appliances may have image interference and noise. (Even if the distance is 1m (39-3/8inch), when there is strong electric wave, noise may still occur.)

Unit: mm (inch)




Fig.3.2

NOTICE
(1) Installation of the unit must be in accordance with National Electric Codes and local regulations.
(2) Improper installation will affect unit's performance, so do not install the unit by yourself. Please contact local dealer to arrange professional technicians for the installation.
(3) Do not connect power until all installation work is finished.

3.3 Requirements for Communication Line

NOTICE

If air conditioner used under strong electronic-magnetic interference circumstance, STP (shielded twisted pair) communication cable must be adopted.

3.3.1 Select communication Line for Indoor Unit and Wired Controller




Fig.3.3.1

Wire type	Total length of communication wire between indoor unit and wired controller	Numbers×size	Remarks
Light/Ordinary polyvinyl chloride sheathed cord.	$L \leq 250m$ ($L \leq 820-1/5ft.$)	2×AWG18~2×AWG16	1. Total length of communication line can't exceed 250m (820-1/4ft.). The average length of the communication line between indoor unit and wired controller is 15m(49-1/4 ft.). (the total length of communication wire for different wired controller should refer to the wired controller manual.) 2. The cord shall be Circular cord (the cores shall be twisted together). 3. If unit is installed in places with intense magnetic field or strong interference, it is necessary to use shielded wire.

3.3.2 Select Communication Line for Indoor Unit and Outdoor Unit




Fig.3.3.2

Wire type	Total length of communication wire between indoor unit and indoor unit(outdoor unit)	Numbers×size	Remarks
Light/Ordinary polyvinyl chloride sheathed cord.	$L \leq 1000\text{m}$ ($L \leq 3280\text{-}5/6\text{ft.}$)	$\geq 2 \times \text{AWG}18$	1. If the wire diameter is enlarged to $2 \times 1 \text{ mm}^2$, the total communication line length can reach 1500m (4921-1/4ft.). The average length of communication line between units is 12.5m (41-1/8 ft.). 2. The cord shall be Circular cord (the cores shall be twisted together). 3. If unit is installed in places with intense magnetic field or strong interference, it is necessary to use shielded wire.

3.4 Wiring Requirements

Power Cord Size and Air Switch Capacity

Models	Power Supply	MCA(A)	MOP(A)
GMV-ND72PH/A-T(U)	208/230V-1ph-60Hz	6.3	15
GMV-ND96PH/A-T(U)		7.5	15

NOTICE	
(1)	Use copper wire only as unit's power cord. Operating temperature should be within its rated value.
(2)	If the power cord is more than 15m (49-1/4ft.) long, please increase properly the sectional area of power cord to avoid overload, which may cause accident.
(3)	Above selection requirements: Power cord size is based on BV single-core wire (2~4pc) at 40°C (104 °F) Ambient temperature when laying across plastic pipe. Air switch is D type and used at 40°C (104 °F). If actual installation condition varies, please lower the capacity appropriately according to the specifications of power cord and air switch provided by manufacturer.
(4)	Install cut-off device near the unit. The minimum distance between each stage of cut-off device should be 3mm (1/8inch) (The same for both indoor unit and outdoor unit).

4 Installation Instructions

NOTICE

- ① This series duct type unit is only for one room.
- ② Vibration isolation, acoustic insulation, and noise control measures must be implemented during installation.

4.1 Installation of Indoor Unit

4.1.1 Outline Dimension and Installation Spots

Equip with an inspection hatch after lifting the unit. For the convenience of maintenance, the service port should be on one side of the electric box and below unit's lower level.

Below are the outline dimensions applicable to indoor units:




Fig.4.1.1

Below are dimensions of A, B, C, etc. for different models:

Unit: mm (inch)

Models	A	B	C	D	E	F
GMV-ND72PH/A-T(U)	1353 (53-1/4)	632 (24-7/8)	992 (39)	1150 (45-1/4)	192 (7-1/2)	327 (12-7/8)
GMV-ND96PH/A-T(U)	1563 (61-1/8)	707 (27-13/16)	992 (39)	1350 (53-1/8)	192 (7-1/2)	402 (15-7/8)

4.1.2 Suspend the indoor unit

(1) Drill bolt holes and install bolts

- 1) Stick the reference cardboard on the installation position; drill 4 holes according to the hole site on the cardboard as shown in Fig.4.1.2; diameter of drilling hole is according to the diameter of expansion bolt and the depth is 60-70mm (2-3/8~2-3/4inch), as shown in Fig.4.1.3.




Fig.4.1.2

Fig.4.1.3

- 2) Insert the M10 expansion bolt into the hole and then knock the nail into the bolt, as shown in Fig.4.1.4, and then remove the paper pattern.

NOTICE

The length of bolt depends on the installation height of the unit, bolts are field supplied.




Fig.4.1.4

(2) Install the indoor unit temporarily

Assemble suspension bolt on the expansion bolt, attach the hanger bracket to the suspension bolt. Be sure to fix it securely by using a nut and washer from upper and lower sides of the hanger bracket. The washer fixing plate will prevent the washer from falling.

NOTICE

- ① Before operation, please prepare all pipelines (connection pipe, drainage hose) and wires (connection wire for wired controller, connection wire for indoor unit).
- ② When drilling holes on ceiling (air return outlet or air outlet), you may need to reinforce the ceiling to prevent vibration. For details, please consult with user or builder.
- ③ If the strength of the ceiling is not good, please install a beam bracket, and then put the unit on the beam bracket.
- (3) Adjust the unit to the right position.
- (4) Check the level of the unit.

After the indoor unit is installed, remember to check the horizontal status of the whole unit. It should be horizontal from front to back and slant 1% from left to right, following the drainage direction.




Fig.4.1.5

(5) Remove the washer locating plate and then tighten the nut on it.




Fig.4.1.6

4.2 Refrigerant Pipe Connection

- (1) Aim the flaring port of copper pipe at the center of screwed joint and then tighten the flaring nut with hand as shown in Fig.4.2.
- (2) Tighten the flaring nut with torque wrench.




Fig.4.2

Torque for tightening nut

Pipe diameter mm (inch)	Torque (N·m)
9.52(3/8)	35-40
15.9(5/8)	60-65
19.05(3/4)	70-75

- (3) Use pipe bend when bending the pipe and the bending angle should not be too small.
- (4) Wrap the connection pipe and joint with sponge and then tie them firmly with tape.
- (5) Prior to installation, the internal piping must be free of contaminants and protected against dust ingress. Any contamination may compromise the unit's operational integrity.
- (6) When cutting or deburring pipes, do not allow cutting chips or other foreign matters to enter the pipes. If cutting chips or other foreign matters enter pipes, wipe them off the inside of the pipes.
- (7) Tighten all flare nuts to specification using a torque wrench. If tightened too much, the flare nut can break after an extended period and refrigerant can leak out.

4.3 Drainage Pipe Installation and Drainage System Testing

4.3.1 Notice for Installation of Drain Pipe

- (1) It is not allowed to connect the condensate drain pipe into waste pipe or other pipelines which are likely to produce corrosive or peculiar smell to prevent the smell from entering indoors or corrupt the unit.
- (2) Incorrect installation of the indoor unit may result in inadequate drainage, potentially causing bacterial growth and associated health hazards. Inadequate drainage may also lead to corrosion of the unit
- (3) Setting the unit at an angle opposite to the drain piping might cause leaks.
- (4) It is not allowed to connect the condensate drain pipe into rain pipe to prevent rain water from pouring in and cause property loss or personal injury.
- (5) Condensate drain pipe should be connected into special drain system for air

conditioner.

- (6) The drainage pipe should be short and the gradient downwards should be at least 1%~2% in order to drain condensation water smoothly.
- (7) The diameter of drainage hose should be bigger or equal to the diameter of drainage pipe joint.
- (8) Install drainage pipe according to the following fig and arrange insulation to the drainage pipe. Improper installation may lead to water leakage and damp the furniture and other things in the room.
- (9) You can buy normal hard PVC pipe used as the drainage pipe. During connection, insert the end of PVC pipe into the drainage hole and then tighten it with drainage hole and wire binder. Can't connect the drainage hole and drainage hole with glue.
- (10) When the drainage pipelines are used for several units, the position of pipeline should be about 100mm (4inch) lower than the drainage port of each unit. In this case, thicker pipes should be applied.




Fig.4.3.1

4.3.2 Drainage Pipe Installation

- (1) Insert the drain hose into the drain hole and tighten it with tapes, as shown in Fig.4.3.2. Model with water pump will be provided with drain hose, while other models please prepare the drain hose by yourself.
- (2) Tighten the pipe clamp, with the distance between screw nut and hose smaller than 4mm (3/16inch).
- (3) Use sealing plate to make the pipe clamp and hose insulated, as shown in Fig.4.3.3.




Fig.4.3.2

Unit: mm (inch)




Fig.4.3.3

- (4) When connecting several drain pipes, follow the instruction as indicated in Fig.4.3.4. Choose the drain collecting pipe that matches with unit capacity.

Unit: mm (inch)




Fig.4.3.4

- (5) Install the trap as shown in following Fig.4.3.5.




Fig.4.3.5

- (6) Install one trap for each unit.
- (7) Convenience for cleaning trap in the future should be considered when installing it.
- (8) The horizontal pipe can be connected to vertical pipe in the same level; please select the connection way as shown in following fig.

No.1: Connection of drainage pipe joints (Fig.4.3.6)

No.2: Connection of downspout elbow (Fig.4.3.7)

No.3: Inserting pipe connection (Fig.4.3.8)




Fig.4.3.6




Fig.4.3.7




Fig.4.3.8

- (9) Drain pipes should have a downward slope of at least 1%~2%, in order to prevent pipes from sagging, install hanger bracket at intervals of 1000~1500 mm (39-3/8~59 inch).




Fig.4.3.9

4.3.3 Test of Drainage System

- (1) Inject approximately 1L purified water to drain pan from air vent, ensure that not to splash the water over the electrical components (e.g. water pump. etc.).
- (2) During the test, please carefully check the drainage joint, make sure no any leakage occur.
- (3) It is strongly recommended to do the drain test before ceiling decoration.




Fig.4.3.10

4.4 Installation of Air Duct

NOTICE

- ① There should be insulating layer on air-out duct, air-return duct and fresh air duct to avoid heat loss and moisture. Adhere a nail on the air duct and then add thermal sponge with a layer of tin. Fasten it with a nail cover and then seal the junction with tin tapes. You can also use other materials that have good insulation quality.
- ② Each air-out duct and air-return duct should be fixed on a pre-made board with iron frame. The junction of air duct should be well-sealed in order to prevent air leakage.
- ③ The design and construction of air duct should comply with national requirements.
- ④ The edge of air-return duct is suggested to be more than 150mm (5-7/8inch) away from the wall. Add a filter to the air-return opening.
- ⑤ Please consider noise-damping and vibration damping for the design and construction of air duct. Besides, noise source must be away from people. For instance, do not have the air-return opening installed on top of the user (Offices, rest area, etc.).
- ⑥ When removing the air filter, wear appropriate eye protection. Include gas handling procedures to prevent exposure to toxic and hazardous gases.

4.4.1 Installation of Air-out Duct

Installation of the Rectangular Duct




Fig.4.4.1

4.4.2 Shape and Size of Air Outlet and Air-return Opening




Fig.4.4.2 Air Outlet




Fig.4.4.3 Air-return Opening

Unit: mm (inch)

Models	Size of Air Outlet		Size of Air –return Opening	
	A	B	C	D
GMV-ND72PH/A-T(U)	192 (7-1/2)	992 (39)	1150 (45-1/4)	327 (12-7/8)
GMV-ND96PH/A-T(U)	192 (7-1/2)	992 (39)	1350 (53-1/8)	402 (15-7/8)

4.5 Installation of Wired Controller

Please refer to User Manual of Wired Controller for the installation details.

NOTICE

When installation is finished, the unit must be tested and debugged before operation.
Please refer to Instruction Manual of ODU for debugging details.

4.6 External Static Pressure Settings

Unit parameters can be set in unit ON or OFF status.

- (1) Long press FUNCTION button for 5s and the temperature zone displays “C00”; long press.

FUNCTION button for another 5s to enter the interface of setting wired controller parameters. “P00” is displayed in temperature zone;

- (2) Press “▲” or “▼” button to select parameter code. Press MODE button to enter parameter setting. At that time, parameter value is blinking. Press “▲” or “▼” button to adjust the parameter value and press ENTER/CANCEL button to finish setting.
- (3) Press ENTER/CANCEL button to return to last step until exists setting parameters.

The parameter setting list is as following

Parameter code	Parameter name	Parameter range	Default value	Note
P30	Set static pressure of indoor fan motor	01-09: static pressure level of indoor fan motor	05	There are two kinds of static pressure level: 5 levels: 03, 04, 05, 06, 07 9 levels: 01, 02, 03, 04, 05, 06, 07, 08, 09 Static pressure level range is different for different models; the wired controller will automatically select static pressure level range of indoor fan motor according to the model of indoor unit.

NOTICE

- ① Under parameter setting status, FAN, TIMER, SLEEP and SWING button are invalid. Press ON/OFF button to go back to home page, but not turning on/off the unit.
- ② If the power cord is more than 15m (49-1/4ft.) long, please increase properly the sectional area of power cord to avoid overload, which may cause accident.

External Static Pressure	Static pressure level of indoor fan motor
0.20 inWG(50 Pa)	01
0.24 inWG(60 Pa)	02
0.28 inWG(70 Pa)	03
0.36 inWG(90 Pa)	04
0.40 inWG(100 Pa)	05
0.48 inWG(120 Pa)	06
0.60 inWG(150 Pa)	07
0.72 inWG(180 Pa)	08
0.80 inWG(200 Pa)	09

NOTICE

- ① Keep in mind that a shortage of airflow quantity or water leakage will result because the air conditioner will be operated outside the rated range of airflow quantity if the external static pressure is wrongly set.
- ② The Sound Pressure Level will change if the external static pressure is wrongly set.

5 Wiring Work

⚠ WARNING

Before obtaining access to terminals, all supply circuits must be disconnected.

NOTICE

(1) Units must be earthed securely, or it may cause electric shock.
(2) Please carefully read the wiring diagram before carry out the wiring work, incorrect wiring could cause malfunction or even damage the unit.
(3) The unit should be powered by independent circuit and specific socket.
(4) The capacity of power supply must be sufficient and the sectional area of wires in the room should be above 2.5mm ² .
(5) The wiring should be in accordance with related regulations in order to ensure the units reliable running.
(6) Install circuit breaker for branch circuit according to related regulations and electrical standards.
(7) All wiring must use pressure terminal or single wire. Multi-twisted wire that connects directly to the wiring board may cause fire hazard.
(8) Keep cable away from refrigerant pipings, compressor and fan motor.
(9) Do not change the internal wiring of the air conditioner; otherwise, our company will not bear relevant legal responsibilities for the related damages.
(10) If the unit is installed in places with strong electromagnetic interference, it's recommended to use twin-twisted shield wire. During wire connection, please pay attention that the metal shield layer of the twin-twisted wire must be grounded (outer case) in order to prevent the unit from electromagnetic interference.
(11) The communication wires should be separated from power cord and connection wire between indoor unit
(12) The electric wire can't be expanded by connecting another electric wire. When the length of the electric wire is not enough, please contact our designated dealer or local service center for a special electric wire.
(13) Adjust the static pressure via wired controller according to site circumstance.
(14) When wiring, position the wires so that the electrical components box lid can be securely fastened.
(15) Be sure to attach the sealing material or putty (field supplied) to hole of wiring to prevent the infiltration of water as well as any insects and other small creatures from outside. Otherwise a short-circuit may occur inside the electrical components box.
(16) Use round crimp-style terminals for connecting wires to the power supply terminal block.
(17) Never connect power supply wiring to the terminal block for remote controller wiring. A mistake of the sort could damage the entire system.
(18) A single switch can be used to supply power to units on the same system. However, branch switches and branch ground fault circuit interrupters must be selected carefully.
(19) If the connecting wire is incorrectly connected to the terminal block, the unit does not operate normally.

5.1 Connection of Wire and Patch Board Terminal

- (1) The connection of wire (as shown in Fig.5.1.1)
 - 1) Strip about 25mm (1inch) insulation of the wire end by stripping and cutting tool.
 - 2) Remove the wiring screws on the terminal board.
 - 3) Shape the tail of wire into ring by needle nose plier, and keep the gauge of ring in accordance with screw.
 - 4) Use the screwdriver for tightening the terminal.
- (2) The connection of stranded wire (as shown in Fig.5.1.2)
 - 1) Strip about 10mm (3/8inch) insulation of the end of stranded wire by stripping and cutting tool.
 - 2) Loosen the wiring screws on terminal board.
 - 3) Insert the wire into the ring tongue terminal and tighten by crimping tool.

- 4) Use the screwdriver for tightening the terminal.

Unit: mm (inch)




Fig.5.1.1





Fig.5.1.2

5.2 Power Cord Connection

NOTICE

Every unit should be equipped with a circuit breaker for short-circuit and overload protection. During operation, all indoor units connected to the same outdoor unit system must be kept energized status. Otherwise, the unit can't operate normally.

Three-phase power



- 1 NOTICE** (1) Connect wires for single-phase unit according to figure ① and connect wires for three-phase unit according to figure ②. As for some areas where there's no neutral wire, please refer to the wiring diagram of unit for details.
- (2) The maximum connection quantity "n" for indoor unit is decided by the capacity of outdoor unit. Please refer to the unit capacity of unit for details.

Fig.5.2

- (1) Detach the electric box lid.
- (2) Let the power cord pass through the wiring through-holes.
- (3) Connect wires according to Fig. 5.2.
- (4) Fix the power cord with wiring clamp.
- (5) The wire diameter of power cord can't be less than 18AWG.

5.3 Connection of Communication Wire between Indoor Unit and Outdoor Unit (or indoor unit)

- (1) Detach the electric box lid.
- (2) Let the Communication cable pass through the wiring through-holes.
- (3) Connect the communication wire to terminal D1 and D2 of indoor 4-bit wiring board, as shown in Fig.5.3.1.





Fig.5.3.1



NOTICE Indoor unit quantity n is according to the outdoor unit capacity.

Fig.5.3.2

- (4) Fix the communication cable with clamp of electric box.
- (5) For more reliable communication, make sure connect the terminal resistor to the most downstream IDU of the communication bus (terminal D1 and D2), as shown in Fig.5.3.2, terminal resistor is provided with each ODU.

5.4 Connect Communication Wire of Wired Controller

- (1) Open electric box cover of indoor unit.
- (2) Let the communication wire go through the rubber ring.
- (3) Connect the communication wire to terminal H1 and H2 of indoor 4-bit wiring board.
- (4) Fix the communication wire with wire clip on the electric box.
- (5) Wiring instructions of remote receiving light board and wired controller:
 - 1) Fig.5.4.1 shows the installation of wired controller.




Fig.5.4.1

Fig.5.4.2

- 2) Fig.5.4.2 shows the installation of remote controller.
- 3) Wired controller and receiving light board can be installed at the same time. When operating through a remote controller, both wired controller and the receiving light board can receive the signals, as shown in Fig.5.4.3.




Fig.5.4.3

5.5 Illuminate for Connection of Wired Controller and Indoor Units Network

- (1) Communication wire of indoor unit and outdoor unit (or indoor unit) is connected to D1, D2.
- (2) Wired controller is connected to H1, H2.
- (3) One indoor unit can connect two wired controllers that must be set as master one and slave one.
- (4) One wired controller can control 16 indoor units in maximum at the same time (As shown in Fig.5.5).

NOTICE

- (1) The type of indoor units must be the same if they are controlled by the same wired controller.
- (2) When the indoor unit is controlled by two wired controllers, the addresses of the two wired controllers should be different through address setting. Address 1 is for main controller; Address 2 is for slave controller. Detailed setting please refer to the instruction manual of wired controller.




Fig.5.5

6 Routine Maintenance

<i>NOTICE</i>	
(1)	Do turn off the unit and cut off the main power supply when cleaning the air conditioner to avoid electric shock or injury.
(2)	Stand at solid table when cleaning the unit.
(3)	Do not clean the unit with hot water whose temperature is higher than 45°C (113°F) to prevent fade or deformation.
(4)	Do not dry the filters by fire, or it may catch fire or become deformed.
(5)	Clean the filter with a wet cloth dipped in neutral detergent.
(6)	Please contact after-sales service staff if there is abnormal situation.

6.1 Cleaning of Filter

- (1) Remove the filters from inlet of IDU. Use a vacuum cleaner to remove dust. If the filters are dirty, wash them with warm water and mild detergent, and dry the filters in the shade.
- (2) If the unit used in the environment with much dust, please clean it regularly. (Usually once every two weeks).

6.2 Maintenance before the Seasonal Use

- (1) Check if the air inlet and air outlet of indoor and outdoor unit are blocked.
- (2) Check if securely grounded.
- (3) Check if all the power cord and communication cable are securely connected.
- (4) Check if any error code displayed after energized.

6.3 Maintenance after the Seasonal Use

- (1) Set the unit in fan mode for half a day in a sunny day to dry the inner part of unit;
- (2) When the unit won't be used for a long time, please cut off power supply for energy saving; the characters on the wired controller screen will disappear after cutting off the power supply.

7 The Table of Error Codes for Indoor Unit

Error Code	Content	Error Code	Content	Error Code	Content
L0	Indoor Unit Error	LA	Indoor Units Incompatibility Error	d9	Jumper Cap Error
L1	Indoor Fan Protection	LH	Low Air Quality Warning	dA	Indoor Unit Network Address Error
L2	E-heater Protection	LC	ODU-IDU Incompatibility Error	dH	Wired Controller PCB Error
L3	Water Full Protection	d1	Indoor Unit PCB Error	dC	Capacity DIP Switch Setting Error.
L4	Wired Controller Power Supply Error	d3	Ambient Temperature Sensor Error	dL	Outlet Air Temperature Sensor Error
L5	Freeze protection	d4	Inlet Pipe Temperature Sensor Error	dE	Indoor Unit CO ₂ Sensor Error
L7	No Master Indoor Unit Error	d6	Outlet Pipe Temperature Sensor Error	dy	Water Temperature Sensor Error
L8	Power Insufficiency Protection	d7	Humidity Sensor Error	C0	Communication Error
L9	Quantity Of Group Control Indoor Units Setting Error	d8	Water Temperature Error	AJ	Filter Cleaning Reminder
db	Special Code: Field Debugging Code				

8 Troubleshooting

The air conditioner is not expected to be serviced by users. Incorrect repair may cause electric shock or fire, so please contact an authorized service center for professional service. The following checks prior to contact may save your time and money.

Phenomenon	Troubleshooting
The unit can't start	① Power supply is not connected. ② Circuit breaker tripping caused by leakage of electricity. ③ Input voltage is too low. ④ Defect of main PC-board.
The unit stops after running for a while.	The inlet or outlet of ODU or IDU are blocked by obstacle.
Poor cooling effect	① The filter is dirty. ② Too heavy heat load of room(e.g. too many people) ③ Door or windows is open. ④ Inlet and outlet of IDU are blocked. ⑤ Setting temperature is too high. ⑥ Refrigerant is insufficient (e.g. refrigerant leakage)
Poor heating effect	① The filter is dirty. ② Door or window is open. ③ Setting temperature is too low. ④ Refrigerant is insufficient (e.g. refrigerant leakage)
Indoor fan doesn't start up during heating	① At starting, the IDU fan could not operate till the heat exchange become hot, for preventing delivering the cool air. ② At defrosting, the IDU fan stopped due to system switch to cooling mode. For preventing delivering the cool air, and resume operating after defrosting.

NOTICE

If air conditioner still fails to work normally after checking and handling as described above, please stop using it immediately and contact local service center for assistance.

Trane - by Trane Technologies (NYSE: TT), a global climate innovator - creates comfortable, energy efficient indoor environments for commercial and residential applications. For more information, please visit trane.com or tranetechnologies.com.

Trane has a policy of continuous product and product data improvement and reserves the right to change design and specifications without notice. We are committed to using environmentally conscious print practices.