Installation Instructions

0 to 50% Manual Fresh Air Damper

Foundation[™] Packaged Rooftop Units 3 to 5 Tons

 Model Number:
 Used With:

 BAYDMPR321*
 E/GB*036-060

 E/GD*036-060
 E/GD*036-060

A SAFETY WARNING

Only qualified personnel should install and service the equipment. The installation, starting up, and servicing of heating, ventilating, and air-conditioning equipment can be hazardous and requires specific knowledge and training. Improperly installed, adjusted or altered equipment by an unqualified person could result in death or serious injury. When working on the equipment, observe all precautions in the literature and on the tags, stickers, and labels that are attached to the equipment.

August 2024

ACC-SVN200D-EN


General Information

The manual fresh air adjustment panel with the hood is designed to provide up to 50 percent outside air. Once the adjustable panel is set and the hood is installed, this will allow a fixed quantity of outside air to be introduced into the conditioned space.

Inspection

- 1. Check carefully for shipping damage. If any damage is found, report it immediately, and file a claim against the transportation company. Replace damaged parts with authorized parts only.
- 2. Compare the order number on the shipping label with the accessory identification information on the ordering and shipping documents to verify that the correct accessory has been received.


Figure 1. Manual damper hood assembly



Warnings, Cautions, and Notices

Read this manual thoroughly before operating or servicing this unit. Safety advisories appear throughout this manual as required. Your personal safety and the proper operation of this machine depend upon the strict observance of these precautions.

The three types of advisories are defined as follows:



Important Environmental Concerns

Scientific research has shown that certain man-made chemicals can affect the earth's naturally occurring stratospheric ozone layer when released to the atmosphere. In particular, several of the identified chemicals that may affect the ozone layer are refrigerants that contain Chlorine, Fluorine and Carbon (CFCs) and those containing Hydrogen, Chlorine, Fluorine and Carbon (HCFCs). Not all refrigerants containing these compounds have the same potential impact to the environment. Trane advocates the responsible handling of all refrigerants.

Important Responsible Refrigerant Practices

Trane believes that responsible refrigerant practices are important to the environment, our customers, and the air conditioning industry. All technicians who handle refrigerants must be certified according to local rules. For the USA, the Federal Clean Air Act (Section 608) sets forth the requirements for handling, reclaiming, recovering and recycling of certain refrigerants and the equipment that is used in these service procedures. In addition, some states or municipalities may have additional requirements that must also be adhered to for responsible management of refrigerants. Know the applicable laws and follow them.

Proper Field Wiring and Grounding Required!

Failure to follow code could result in death or serious injury. All field wiring MUST be performed by qualified personnel. Improperly installed and grounded field wiring poses FIRE and ELECTROCUTION hazards. To avoid these hazards, you MUST follow requirements for field wiring installation and grounding as described in NEC and your local/state/national electrical codes.

A WARNING

Personal Protective Equipment (PPE) Required!

Failure to wear proper PPE for the job being undertaken could result in death or serious injury. Technicians, in order to protect themselves from potential electrical, mechanical, and chemical hazards, MUST follow precautions in this manual and on the tags, stickers, and labels, as well as the instructions below:

- Before installing/servicing this unit, technicians MUST put on all PPE required for the work being undertaken (Examples; cut resistant gloves/sleeves, butyl gloves, safety glasses, hard hat/bump cap, fall protection, electrical PPE and arc flash clothing). ALWAYS refer to appropriate Safety Data Sheets (SDS) and OSHA guidelines for proper PPE.
- When working with or around hazardous chemicals, ALWAYS refer to the appropriate SDS and OSHA/GHS (Global Harmonized System of Classification and Labeling of Chemicals) guidelines for information on allowable personal exposure levels, proper respiratory protection and handling instructions.
- If there is a risk of energized electrical contact, arc, or flash, technicians MUST put on all PPE in accordance with OSHA, NFPA 70E, or other countryspecific requirements for arc flash protection, PRIOR to servicing the unit. NEVER PERFORM ANY SWITCHING, DISCONNECTING, OR VOLTAGE TESTING WITHOUT PROPER ELECTRICAL PPE AND ARC FLASH CLOTHING. ENSURE ELECTRICAL METERS AND EQUIPMENT ARE PROPERLY RATED FOR INTENDED VOLTAGE.

Installation

A WARNING

Hazardous Voltage w/Capacitors!

Failure to disconnect power and discharge capacitors before servicing could result in death or serious injury.


Disconnect all electric power, including remote disconnects and discharge all motor start/run capacitors before servicing. Follow proper lockout/tagout procedures to ensure the power cannot be inadvertently energized. Verify with a CAT III or IV voltmeter rated per NFPA 70E that all capacitors have discharged.

- 1. Open the unit disconnect switch.
- 2. Remove screws securing the fresh air adjustment panel to the units end panel. Do not throw away the screws; they will be used in Step 10.
- Adjust the amount of fresh air desired by changing the position of the fresh air adjustment panel. Refer to Table 1 to Table 3 to determine the correct opening for the specified amount of fresh air, based on the operating return static pressure.
- 4. Secure the fresh air adjustment panel to the unit end panel with two screws.
- 5. Apply the gaskets on the LH and RH panel flange as shown in Figure 1.
- 6. Assemble rear panel onto LH and RH panel with eight screws as shown in Figure 1.
- 7. Using the provided screws, assemble the fresh air hood, as illustrated in Figure 2.
- 8. Install the filter/mist eliminator into the fresh air hood and secure it in place using three screws on each side, as illustrated in Figure 1.

Note: Install the filter/mist eliminator with the arrow pointing in the direction of the airflow. The filter/mist eliminator can be taken out for cleaning by removing the screws installed in Step 8.

9. Install the provided gasket onto the hood mounting flange.

- 10.Install the fresh air hood onto the end panel of the unit using 13 self-tapping screws #10-16 x 1.25 as illustrated in Figure 2.
- 11. Close the unit disconnect switch.



A WARNING

Follow EHS Policies!

Failure to follow instructions below could result in death or serious injury.

- All Trane personnel must follow the company's Environmental, Health and Safety (EHS) policies when performing work such as hot work, electrical, fall protection, lockout/tagout, refrigerant handling, etc. Where local regulations are more stringent than these policies, those regulations supersede these policies.
- Non-Trane personnel should always follow local regulations.

A WARNING

R-454B Flammable A2L Refrigerant!

Failure to use proper equipment or components as described below could result in equipment failure, and possibly fire, which could result in death, serious injury, or equipment damage.

The equipment described in this manual uses R-454B refrigerant which is flammable (A2L). Use ONLY R-454B rated service equipment and components. For specific handling concerns with R-454B, contact your local representative.

Copyright

This document and the information in it are the property of Trane, and may not be used or reproduced in whole or in part without written permission. Trane reserves the right to revise this publication at any time, and to make changes to its content without obligation to notify any person of such revision or change.

Trademarks

All trademarks referenced in this document are the trademarks of their respective owners.




Table 1. Airflow - E/GB*036, E/GD*036

Airflow Adjus. position	Return static - Inch W.C							
	-0.1	-0.2	-0.3	-0.4	-0.5	-0.6	-0.7	
Α	58	80	98	113	127	138	150	
В	170	230	280	325	360	395	425	
С	300	440	545	630	_	_	_	
D	370	510	—	—	_	—	_	
E	470	_	_	_	_	_	_	
W/Open	630	_	_	_	_	_	_	

Table 2. Airflow - E/GB*048, E/GD*048

8

Airflow Adjus. position	Return static - Inch W.C							
	-0.1	-0.2	-0.3	-0.4	-0.5	-0.6	-0.7	
Α	58	80	98	113	127	138	150	
в	170	230	280	325	360	395	425	
С	300	440	545	630	700	770	830	
D	370	510	640	740	830	_		
Е	470	675	_	_	_	_	_	
W/Open	630	_	_	_		_	_	

Table 3. Airflow - E/GB*060, E/GD*060



Table 4. Maximum fresh air CFM

abie 4 .		
	Unit	Max CFM
E	/GB*036, E/GD*036	600
E	/GB*048, E/GD*048	800
E	/GB*060, E/GD*060	1200

Trane and American Standard create comfortable, energy efficient indoor environments for commercial and residential applications. For more information, please visit trane.com or americanstandardair.com.

Trane and American Standard have a policy of continuous product and product data improvement and reserve the right to change design and specifications without notice. We are committed to using environmentally conscious print practices.