



Integration Guide

Touch Screen Programmable Zone Sensor

For Tracer® UC400–B, Symbio 400–B/500/700/800, and ReliaTel™ Controls



⚠ SAFETY WARNING

Only qualified personnel should install and service the equipment. The installation, starting up, and servicing of heating, ventilating, and air-conditioning equipment can be hazardous and requires specific knowledge and training. Improperly installed, adjusted or altered equipment by an unqualified person could result in death or serious injury. When working on the equipment, observe all precautions in the literature and on the tags, stickers, and labels that are attached to the equipment.



Introduction

Read this manual thoroughly before operating or servicing this unit.

Warnings, Cautions, and Notices

Safety advisories appear throughout this manual as required. Your personal safety and the proper operation of this machine depend upon the strict observance of these precautions.

The three types of advisories are defined as follows:



Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



Indicates a potentially hazardous situation which, if not avoided, could result in minor or moderate injury. It could also be used to alert against unsafe practices.



Indicates a situation that could result in equipment or property-damage only accidents.

Important Environmental Concerns

Scientific research has shown that certain man-made chemicals can affect the earth's naturally occurring stratospheric ozone layer when released to the atmosphere. In particular, several of the identified chemicals that may affect the ozone layer are refrigerants that contain Chlorine, Fluorine and Carbon (CFCs) and those containing Hydrogen, Chlorine, Fluorine and Carbon (HCFCs). Not all refrigerants containing these compounds have the same potential impact to the environment. Trane advocates the responsible handling of all refrigerants.

Important Responsible Refrigerant Practices

Trane believes that responsible refrigerant practices are important to the environment, our customers, and the air conditioning industry. All technicians who handle refrigerants must be certified according to local rules. For the USA, the Federal Clean Air Act (Section 608) sets forth the requirements for handling, reclaiming, recovering and recycling of certain refrigerants and the equipment that is used in these service procedures. In addition, some states or municipalities may have additional requirements that must also be adhered to for responsible management of refrigerants. Know the applicable laws and follow them.

⚠ WARNING

Proper Field Wiring and Grounding Required!

Failure to follow code could result in death or serious injury.

All field wiring MUST be performed by qualified personnel. Improperly installed and grounded field wiring poses FIRE and ELECTROCUTION hazards. To avoid these hazards, you MUST follow requirements for field wiring installation and grounding as described in NEC and your local/state/national electrical codes.

⚠ WARNING

Personal Protective Equipment (PPE) Required!

Failure to wear proper PPE for the job being undertaken could result in death or serious injury. Technicians, in order to protect themselves from potential electrical, mechanical, and chemical hazards, **MUST** follow precautions in this manual and on the tags, stickers, and labels, as well as the instructions below:

- Before installing/servicing this unit, technicians **MUST** put on all PPE required for the work being undertaken (Examples; cut resistant gloves/sleeves, butyl gloves, safety glasses, hard hat/bump cap, fall protection, electrical PPE and arc flash clothing). **ALWAYS** refer to appropriate Safety Data Sheets (SDS) and OSHA guidelines for proper PPE.
- When working with or around hazardous chemicals, **ALWAYS** refer to the appropriate SDS and OSHA/GHS (Global Harmonized System of Classification and Labelling of Chemicals) guidelines for information on allowable personal exposure levels, proper respiratory protection and handling instructions.
- If there is a risk of energized electrical contact, arc, or flash, technicians **MUST** put on all PPE in accordance with OSHA, NFPA 70E, or other country-specific requirements for arc flash protection, **PRIOR** to servicing the unit. **NEVER PERFORM ANY SWITCHING, DISCONNECTING, OR VOLTAGE TESTING WITHOUT PROPER ELECTRICAL PPE AND ARC FLASH CLOTHING. ENSURE ELECTRICAL METERS AND EQUIPMENT ARE PROPERLY RATED FOR INTENDED VOLTAGE.**

⚠ WARNING

Follow EHS Policies!

Failure to follow instructions below could result in death or serious injury.

- All Trane personnel must follow the company's Environmental, Health and Safety (EHS) policies when performing work such as hot work, electrical, fall protection, lockout/tagout, refrigerant handling, etc. Where local regulations are more stringent than these policies, those regulations supersede these policies.
- Non-Trane personnel should always follow local regulations.

Copyright

This document and the information in it are the property of Trane, and may not be used or reproduced in whole or in part without written permission. Trane reserves the right to revise this publication at any time, and to make changes to its content without obligation to notify any person of such revision or change.

Trademarks

All trademarks referenced in this document are the trademarks of their respective owners.

Revision History

New



Table of Contents

- Overview 5
 - Purpose 5
 - About the Programmable Zone Sensor 5
 - Supported Equipment and Software 5
 - ReliaTel™ 5
 - Symbio™ 400–B/500, UC400–B 6
 - Symbio™ 700 6
 - Symbio™ 800 6
 - Communication Options 6
 - Communication Wire 6
- Communication Setup and Configuration 7
 - Network Layout 7
 - Device Addressing 7
- Menu Navigation 9
 - Interface Flowchart Part 1 9
 - Interface Flowchart Part 2 9
- BACnet Points 11
 - UC400FC/BC/UV/staged WSHP/VS-WSHP, Symbio 500 13
 - Symbio 800 (SCC IPak)/700 18



Overview

Purpose

The purpose of this document is to provide instructions for integrating the Trane Commercial Touch Screen Programmable Zone Sensor into building automation systems. The intended audience of this document is system integrators and controls contractors.

About the Programmable Zone Sensor

The Trane Commercial and Residential Touch Screen Programmable Zone Sensors are primarily designed to operate in a one-to-one capacity with Trane Water Source Heat Pumps, Blower Coils, Fan Coils and Space Comfort Controller (SCC) Packaged Units. The Sensor allows these units to run independent of a full building automation system and still be controlled by a user-adjustable schedule and to meet title 24 specifications.

The following models are available:

- Commercial Symbio™ 400–B/500 or UC400–B factory programmed units: X13790993001 (SEN02587)
- Residential Symbio™ 400–B/500 or UC400–B factory programmed units: X13790992001
- Commercial ReliaTel™ units: X13790994001 (BAYSENS924)
- Commercial Symbio™ 700/800 units: X13791009001 (BAYSENS800) ReliaTel™

For information on setup and configuration refer to the following documents:

- Trane Commercial Touch Screen Programmable Zone Sensor for Tracer UC400, ReliaTel and Symbio 400/700/800 Controls / User Guide (BAS-SVU040)
- Trane Commercial Touch Screen Programmable Zone Sensor for Tracer UC400, ReliaTel and Symbio Controls / Installation Guide (BAS-SVN028)
- Trane Residential Touch Screen Programmable Zone Sensor for Tracer UC400 Controls / Installation Guide (BAS-SVN026)
- Trane Residential Touch Screen Programmable Zone Sensor for Symbio 400 and Tracer UC400 Controls (BAS-SVU038)

With the release of models mentioned above, the communicating zone sensor and associated controller can be applied as standalone or as part of a building automation system. The primary function of installing the sensor on a building automation system is to provide monitoring and alarming from the unit controller and sensor. The sensor will still need to maintain control over the unit that it is configured to control. The sensor is not designed to work with custom programmed units, nor will it work with non-Trane devices or unit controllers. The sensor utilizes specific BACnet points on the designated units mentioned above to determine how the unit is configured and applies BACnet overrides to those points to affect change based on the user input at the local sensor level.

Note: For communication with third-party control systems, network communication wiring must be provided by others.

Supported Equipment and Software

The four zone sensor models are compatible with the following HVAC equipment and control systems. The communicating sensor is designed for use with space comfort control equipment only. It can be used in a building automation system for the purposes of monitoring and data logging.

ReliaTel™

The programmable zone sensor supports Precedent™, Voyager™ 2, Voyager™ 3, and Odyssey™ Constant Volume (CV)/Single Zone VAV (SZVAV)/Multi-speed indoor fan equipment that uses the ReliaTel control system. For proper operation, the ReliaTel RTRM board must be installed in the equipment with software version 19.2 or later. In addition, the BCI-R board must be installed with software version 6.0 or later. Multiple-zone systems are not supported. In the field, multiple-zone HVAC equipment can be identified by the presence of the ReliaTel RTAM board installed in the equipment.



Symbio™ 400–B/500, UC400–B

The programmable zone sensor supports factory-programmed fan coil, blower coil, and both staged and variable speed water source heat pump equipment that uses the Symbio 400–B/500 or UC400–B control system. Field-programmed Symbio 400–B/500, UC400–B controlled equipment is not supported.

Symbio™ 700

The programmable zone sensor supports all equipment that uses the Symbio 700 control system with the exception of multiple-zone systems.

Symbio™ 800

The programmable zone sensor controls IntelliPak® equipment that uses the Symbio 800 control system.

Communication Options

The Programmable Zone Sensors only support the BACnet MS/TP communication protocol for integration to either Trane or non-Trane control systems.

Communication Wire

Use the correct communication wire to ensure reliable communication between the zone sensor and the HVAC equipment.

Recommended supplier: Windy City Wire.

- Plenum rated P/N: 043005AL
- Non-plenum rated P/N: 108760

Other wire may be used if it conforms with the following physical characteristics:

- Twisted pair (2-conductor) plus shield
- Characteristic Impedance: 100 and 130 ohms
- Distributed capacitance between conductors: <100 pF/m
- Distributed capacitance between conductor and shield: <200 pF/m
- Foil or braided shield is acceptable
- Maximum Length (end to end) —4000 feet with 18 AWG conductor wires
- Maximum Length (end to end) —2000 feet with 22 AWG conductor wires



Communication Setup and Configuration

Network Layout

When using the Trane Commercial and Residential Touch Screen Programmable Zone Sensor with a full building automation system it is no longer necessary to wire together the sensor and the unit controller with a communications wire. Instead, both devices only require the capability to communicate on the overall BACnet network.

This can be done using the same physical link or within the same network. For example, on a Trane job site the unit being controlled could reside on an Air-Fi network while the sensor resides on MST/P link 1 (Fig. 1). Best practice is that both devices must be on the same physical link to reduce the potential for communication loss (Fig. 2).

In some cases, it may be necessary to split Trane and non-Trane devices onto separate links (Fig. 3). The Symbio 500 is shown below, but the layouts are applicable to any Trane BACnet unit controllers.

Figure 1. Zone sensor controlling a unit communicating on an Air-Fi link




Figure 2. Zone sensor wired to same MS/TP link as unit controller





Figure 3. Zone sensor wired to different MS/TP link than unit controller



Device Addressing

To configure BACnet settings:

1. Set the unit controller (Symbio/UC400/UC400-B) to the appropriate MAC address for the BACnet link to which it will be connected.
2. Connect to the unit controller with the Tracer TU, Symbio web UI (supported Symbio controllers only), or the Tracer BACnet Setup Tool. Set the device ID based on network design. For Trane networks, best practice is to use the following device ID assignment:



Communication Setup and Configuration

- BACnet network number of the connected MS/TP link + unit device rotary = device ID
 - Example: SC+ with a rotary address of 001 will (by default) use network 11 for link 1. If the MAC address of the sensor is 001, the device ID will be 11001.
3. Using the sensor display, set the Sens. Address field to the appropriate MAC address for the BACnet network per the job documentation.
 4. Using the sensor display, set the Sens. Device ID field to the value for the BACnet network per the job documentation, or calculation shown above.
 5. Using the sensor display, set the unit device ID field to the same value as the unit controller device ID the sensor is controlling


Table 1. Touch screen addressing functions

| | |
|-----------------------------|---|
| Sens. Address | Sets the sensor BACnet MAC address. (Range of 0-127) |
| Baud rate | Sets the baud rate. Default is 76800 (leave default value unless directed by Trane Technical Support). |
| Status | This setting is not configurable. It indicates that BACnet communication is occurring between the UC/Symbio controller and the sensor. |
| 2/3 Sensor Device ID | Use the number pad to set the BACnet Device ID of the sensor. Touch to Confirm and Save the value. (Range 0 - 4194302). Touching R on this screen copies the sensor MAC address number to the BACnet Device ID field. For example, if the MAC address = 7, touching R sets the Device ID number to 7. |
| 3/3 Unit Device ID | BACnet address of the Unit Controller (Range 0 - 4194302). |

Menu Navigation

Interface Flowchart Part 1

Note: The installer password is 4017 and cannot be changed.




Interface Flowchart Part 2

Tap on Network selection on the 1/2 Setup page to set the BACnet network parameters for the devices

Note: In previous versions of the sensor, the network setup was slightly different and referred to the Units Device ID as the Unit Address.

Figure 4. Network from 1 / 2 setup screen





BACnet Points

When using the Trane Commercial and Residential Touch Screen Programmable Zone Sensors with a full building automation system, it is important to determine how the overall system will interact. Below are the points that interact between the communicating sensor and the unit controller for each unit type. Depending on the desired outcome some points may require the sensor to control, while others can be controlled by either the sensor or the BAS. All commands from the communicating sensor to the Trane unit controller will be at priority level 7. The primary use for placing the devices on a full BAS should be for monitoring, data logging, and alarming. Ideally, control should be done by the communicating sensor.

The points in [Table 2, p. 11](#) are specifically utilized between the two devices. For a complete list of BACnet points on the sensor see the Viconics VT8000 BACnet integration guide.

Table 2. General BACnet points and description

| Control Object/Trane Object Name | Description |
|---|--|
| UC400 Equipment Type | Determine if equipment is VS WSHP or FC/BC/UV/ Staged WSHP. If MV5 is not present the unit is determined to be a VS WSHP. Otherwise, the unit is a FC/BC/UV/Staged WSHP. (It is important to not add MV5 to a VS WSHP for any reason) |
| Network Units (communicating sensor use only) | Communicating sensor determines the temperature units (C or F) being used by the equipment by reading the Units of Measure property of the Space Temperature BAS object. |
| Space Temperature BAS | Space temperature reading from wall sensor. If desired BAS can control at a priority 5 or higher. (Priority 6 cannot be used for control, as it is reserved for minimum On/Off) |
| Space Temperature Setpoint BAS | Space temperature setpoint from the wall sensor. |
| Space Temperature Local | Space temperature reading from sensor hardwired to equipment. Used for ReliaTel w/ remote space sensor. |
| Heat Cool Mode Request | The desired control mode for the equipment, controlled by sensor |
| Heat Cool Mode Status | The actual control mode of the equipment |
| Occupied Offset | <p>The occupied offset value is added or subtracted from the occupied setpoint value to calculate the heating and cooling temperature setpoints.</p> <ul style="list-style-type: none"> ReliaTel only AO30 max value is 10°F AO30 (standby offset) = AO29 (Occupied offset) + (Shed offset) <p>The standby offset (AO30) is used because the BCI-R Occupied Offset object is limited to max 5°F. This range is too small to accommodate the load shed offset.</p> |
| Standby Offset | Symbio and Reliatel only |
| Unoccupied Cooling Setpoint | Unoccupied cooling setpoint |
| Unoccupied Heating Setpoint | Unoccupied heating setpoint |
| Occupancy Request Command | The desired occupancy state for the equipment, controlled by sensor |
| Supply Fan Configuration Command | Defines how the equipment fan should operate |
| Supply Fan Speed Status | The current speed of the equipment fan as a percent of full speed |
| Economizing Temp Enable | The value the OA temperature must be less than before economizing is allowed (Optional) |
| Economizing Enthalpy Enable | The value the OA enthalpy must be less than before economizing is allowed (optional) |
| Outdoor Air Temperature | Outdoor Air Temperature (optional) |
| Discharge Air Temperature | Discharge Air Temperature |
| Return Air Temperature | Return Air Temperature (Optional) |
| Mixed Air Temperature | Mixed Air Temperature (Optional) |
| Space Humidity | Space Humidity, Object is always present, but may be configured as not used by placing the object Out of Service |



BACnet Points

Table 2. General BACnet points and description (continued)

| Control Object/Trane Object Name | Description |
|---|--|
| Outdoor Humidity | Outdoor Humidity (Optional) |
| Economizer System Status | Economizer System Status (optional) |
| Outdoor Air Damper Position Status | Outdoor Air Damper Position Status (optional) |
| Economizer Active | Is the unit actively economizing for cooling. (optional) |
| Cooling Capacity Status | Percent of mechanical cooling (0 to 100 %) (optional) |
| Heat Primary Capacity Status | Percent of mechanical primary heating. (0 to 100 %) (optional) |
| Heat Secondary Capacity Status | Percent of mechanical secondary heating. (0 to 100 %) (optional) |

UC400FC/BC/UV/staged WSHP/VS-WSHP, Symbio 500

Table 3. UC400FC/BC/UV/staged WSHP/VS-WSHP, Symbio 500 points

| Object name | UC400 WSHP Object | UC400 VS-WSHP Object | Communicating sensor Object Residential | Communicating sensor Object Commercial | Write Out of Service property at power-up | Value written to Out of Service Property | Present Value Range and Default Value | Default Value | Units of Measure | Point Always Available |
|---|-------------------|----------------------|---|--|---|--|---|---------------|------------------------|------------------------|
| Space Temperature BAS | AV 14 | AV 14 | AV 100 | AV 100 | Yes | 0 | -40 °F – 150 °F | N/A | Temperature (°F or °C) | Yes |
| Space Temperature Local (TempRemSrc) | AI 1 | AI 1 | N/A | N/A | No | 1 | -40 – 200 °F | N/A | Temperature (°F or °C) | Yes |
| Unoccupied Cooling Setpoint | AV 23 | AV 23 | N/A | AV 44 | Yes | 0 | 50 °F – 90 °F | 85 °F | Temperature (°F or °C) | Yes |
| Unoccupied Heating Setpoint | AV 24 | AV 24 | N/A | AV 43 | Yes | 0 | 50 °F – 90 °F | 60 °F | Temperature (°F or °C) | Yes |
| Space Temperature Setpoint BAS | AV 27 | AV 27 | (AV/222+AV/223)/2 | (AV/40 + AV/39) / 2 | Yes | 0 | 50 °F – 90 °F | 72.5 °F | Temperature (°F or °C) | Yes |
| Occupied Offset (See Note 4) | AV 30 | AV 30 | (AV/222-AV/223)/2 | (AV/40 - AV/39) / 2 | Yes | 0 | 1 °F – 5 °F | 1.5 °F | Temperature (°F or °C) | Yes |
| Supply Fan Speed Status | AI 73 | AV 6 | MV 140 | MV 140 | No | N/A | 0 – 100% | N/A | Percent | Yes |
| Heat Cool Mode Request BAS | MV4 | MV 3 | MV 16 | MV 16 | Yes | 0 | See Note 3 | Auto | N/A | Yes |
| Heat Cool Mode Status BAS | MV5 | MV4 | MV 112 | MV 112 | No | N/A | See Note 3 | N/A | N/A | Yes |
| Occupancy Request | MV 6 | MV 1 | MI 33 | MI 33 | Yes | 0 | 1 = Occupied 2 = Unoccupied 3 = Occupied Bypass 4 = Occupied Standby | Occupied | N/A | Yes |
| Supply Fan Configuration Command | BV 1 | BV 2 | MV 17 | MV 17 | Yes | 0 | Inactive = Auto Active = On | Auto | N/A | Yes |
| Cooling Capacity Status | AV 76 | AV 12 | N/A | MV 172 | | | 0 – 100% | | ON/OFF | |
| Heat Primary Capacity Status | AV 74 | AV 13 | N/A | MV 173 | | | 0 – 100% | | ON/OFF | |
| Heat Secondary Capacity Status | AV 75 | NA | N/A | MV 174 | | | 0 – 100% | | ON/OFF | |
| Economizing Temperature Enable Setpoint | NA | NA | N/A | AV 260 | NA | NA | NA | NA | NA | NA |
| Economizing Enthalpy Enable Setpoint | NA | NA | N/A | AV 261 | NA | NA | NA | NA | NA | NA |

Fault Detection and Diagnostics

The Communicating Sensor will display the following information either at the controller user interface or via BACnet MS/TP. To view the diagnostics and fault information, navigate to the zone sensor Service View Menu screen beginning at page 1 / 7.

The Communicating Sensor displays the following information () either at the screen interface of the control or through BACnet MS/TP. Fault detection for the UC400–B/Symbio 400–B and Symbio500 units is limited to the Space Temperature Sensor.

If the temperature source is wired or remote and there is a temperature sensor failure, a message will be displayed on the communicating sensor (Temperature sensor failure). In the event of a temperature sensor failure, the source for temperature will fail-over to the internal or on-board 10k sensor element of the communicating sensor.

The effective temperature (Service View – 1/7) becomes internal temperature and is sent to space temperature BAS. When the wired sensor is restored, the effective temperature reverts to the wired source.

Table 4. ReliaTel BCI-R

| Object name | ReliaTel Object | Communicating sensor Object | Write Out of Service property at power-up | Value written to Out of Service Property | Present Value Range and Default Value | Default Value | Units of Measure | Point Always Available |
|---|-----------------|--|---|--|---|------------------------|------------------------|------------------------|
| Space Temperature BAS | AO 11 | AV100 | Yes | 0 | -40 °F - 150 °F | N/A | Temperature (°F or °C) | Yes |
| Space Temperature Local (TempRemSrc) | AI87 | N/A | No | 1 | -40 - 200 °F | N/A | Temperature (°F or °C) | Yes |
| Unoccupied Cooling Setpoint | AO 31 | AV44 | Yes | 0 | 50 °F - 90 °F | 85 °F | Temperature (°F or °C) | Yes |
| Unoccupied Heating Setpoint | AO 32 | AV43 | Yes | 0 | 50 °F - 90 °F | 60 °F | Temperature (°F or °C) | Yes |
| Space Temperature Setpoint BAS | AO 2 | (AV39 + AV40)/2 | Yes | 0 | 50 °F - 90 °F | 72.5 °F | Temperature (°F or °C) | Yes |
| Occupied Offset (See Note 4) | AO 30 | (spCool - spHeat) / 2 (AV40 - AV39) / 2 | Yes | 0 | 1 °F - 5 °F | 1.5 °F | Temperature (°F or °C) | Yes |
| Supply Fan Speed Status | AI 7 | MV140 | No | N/A | 0 - 100% | N/A | Percent | Yes |
| Heat Cool Mode Request BAS | MO 8 | MV16 | Yes | 0 | See Note 3 | Auto | N/A | Yes |
| Heat Cool Mode Status BAS | MI 19 | MV112 | No | N/A | See Note 3 | N/A | N/A | Yes |
| Occupancy Request | MO 7 | MI33 | Yes | 0 | 1 = Occupied 2 = Unoccupied 3 = Occupied Bypass 4 = Occupied Standby | Occupied | N/A | Yes |
| Supply Fan Configuration Command | BO 8 | MV17 | Yes | 0 | Inactive = Auto Active = On | Auto | N/A | Yes |
| Economizing Temperature Enable Setpoint | AO 41 | AV260 | Yes | See Note 1 | 50.0 °F - 140.0 °F | Disabled and 63 °F | Temperature (°F or °C) | No |
| Economizing Enthalpy Enable Setpoint | AO 42 | AV261 | Yes | See Note 1 | 19.0 to 28.0 | Disabled and 22 BTU/LB | BTU per LB | No |
| System Control Command | BO 1 | N/A | No | N/A | FALSE = Standalone Control TRUE = BAS Control | N/A | See NOTE 2 | Yes |



BACnet Points

Table 5. ReliaTel BCI-R fault detection and diagnostics

| | BACnet points / Diagnostics messages | Display name / value | Range |
|--|--|--|---|
| Sensor Values | AI-18 (Outdoor Air Temperature Active) | OA Temp | -40 to 158°F |
| | AI-24 (Discharge Air Temperature Active) | DA Temp | -40 to 158°F |
| | AI-26 (Return Air Temperature) | RA Temp | 32 to 209 °F |
| | AI-25 (Mixed Air Temperature) AI-16 Space Humidity Active AI-20 Outdoor Air Humidity Active | MA Temp RH OA RH | -40 to 150 °F 0 to 100% 0 to 100% |
| Economizer | Economizer Available: MSI-44 (Economizer System Status) | Econ Available | Yes/No |
| | Economizer Active: MSI-44 =2 (Enabled) AND AI-11 (Outdoor Air Damper Position Status) is above Minimum Position/Opening (AI-86) AND MSI-19 (Application Mode Status) is [4] Cooling | Econ Active | On/Off |
| Compressor (Cooling) | AI-1 (Cooling Capacity Status) > 0 = Cooling ON | Cooling On / Off | On/Off |
| Heating (HP and Auxiliary) | AI-2 (Heat Primary Capacity Status) > 0 = Primary Heat ON | Primary heat On / Off | On/Off |
| | AI-3 (Heat Secondary Capacity Status) > 0 = Secondary Heat ON | Secondary heat On / Off | On/Off |
| Diagnostics | BI-310 (Diagnostic: Mixed Air Temp Low Limit Cycle Active) | The technician needs a way to see the active error messages. Any of these active diagnostic BI (except BI-310) will trig to display bottom of main user screen Contact service | On/Off |
| | BI-30 (Diagnostic: Supply Air Temp Sensor Fail) | | |
| | BI-32 (Diagnostic: Outdoor Air Temperature Sensor Failed) | | |
| | BI-57 (Diagnostic: Return Air Temp Sensor Fail) | | |
| | BI-95 (Diagnostic: Mixed Air Temp Sensor Failure) | | |
| | BI-306 (Diagnostic: Unit Not Economizing When it Should Be) | | |
| | BI-305 (Diagnostic: Unit Economizing When It Should Not) | | |
| | BI-308 (Diagnostic: Outdoor Air Damper Not Modulating) | | |
| BI-307 (Diagnostic: Excessive Outdoor Air) | | | |

NOTE 1

For AO41 and AO42, users can enable/disable the use of these setpoints through the sensor display. For clarification, page 2/4 of the Configuration Menu – Econo Enable is the economizer enable/disable configuration item.

- To enable the use of the setpoint, set the value in the sensor display to In Use. This causes a BACnet value of FALSE to be written to the Out_of_Service property of the object. The Out_of_Service property should only be written to Once on change and power-up. Periodic refresh is not recommended.
- To disable use of the setpoint, set the value in the sensor display to Not Used. This causes a BACnet value of TRUE to be written to the Out_of_Service property of the object. The Out_of_Service property should only be written to Once. Periodic refresh is not recommended.

This functionality is in the setup/commissioning portion of the zone sensor user interface. End users do not have access to this configuration functionality.

NOTE 2

BO1, Present_Value from the factory defaults to Inactive. The sensor writes Active at VT8300 power-up. Periodic refresh is not recommended.

NOTE 3

The following table displays the enumerated state values for the Heat Cool Mode objects.

| | |
|---------------------|--------------------|
| 1 = Auto | 9 = Emergency Heat |
| 2 = Heat | 10 = Fan Only |
| 3 = Morning Warm-up | 11 = Free Cool |
| 4 = Cool | 12 = Ice Making |
| 5 = Night Purge | 13 = Max Heat |
| 6 = Precool | 14 = Economy Mode |
| 7 = Off | 15 = Dehumidifying |
| 8 = Test | 16 = Calibrate |

NOTE 4

The occupied offset value is added or subtracted from the occupied setpoint value to calculate the heating and cooling temperature setpoints.

ReliaTel only

- AO30 max value is 10°F
- $AO30 \text{ (standby offset)} = AO29 \text{ (Occupied offset)} + \text{(Shed offset)}$
- The standby offset (AO30) is used because the BCI-R Occupied Offset object is limited to max 5°F; this range is too small to accommodate the load shed offset.

Symbio 800 (SCC IPak)/700

Table 6. Symbio 800 (SCC IPak)/700 points

| Object name | Symbio Object | Communicat- ing sensor Object | Write Out of Service property at power-up Note 2 | Value written to Out of Service Property Note 2 | Present Value Range and Default Value | Default Value | Units of Measure | Point Always Available |
|--|-------------------|-------------------------------------|--|---|---|---------------------------|------------------------|------------------------------|
| Space Temperature BAS | AV1014 | AV 100 | NA | NA | -40 °F – 150 °F | N/A | Temperature (°F or °C) | Yes |
| Space Temperature Local (TempRemSrc) | A10218 | N/A | NA | NA | -40 – 200 °F | N/A | Temperature (°F or °C) | Yes |
| Unoccupied Cooling Setpoint | AV10123 | AV 44 | NA | NA | 50 °F – 90 °F | 85 °F | Temperature (°F or °C) | Yes |
| Unoccupied Heating Setpoint | AV10124 | AV 43 | NA | NA | 50 °F – 90 °F | 60 °F | Temperature (°F or °C) | Yes |
| Space Temperature Setpoint BAS | AV10127 | (AV39+AV40)/2 | NA | NA | 50 °F – 90 °F | 72.5 °F | Temperature (°F or °C) | Yes |
| Occupied Offset | AV10130 | (AV40 - AV39) / 2 | NA | NA | 1 °F – 5 °F | 1.5 °F | Temperature (°F or °C) | Yes |
| Occupied Standby Offset | AV10142 | NA | NA | NA | 1 °F – 5 °F | 1.5 °F | Temperature (°F or °C) | Yes |
| Supply Fan Speed Status | A10173 | MV 140 | NA | NA | 0 – 100% | N/A | Percent | Yes |
| Heat Cool Mode Request BAS | MV10104 | MV 16 | NA | NA | See Note 3 | Auto | N/A | Yes |
| Heat Cool Mode Status BAS | M10101 | MV 112 | NA | NA | See Note 3 | N/A | N/A | Yes |
| Occupancy Request | MV10106 | M1 33 | NA | NA | 1 = Occupied 2 = Unoccupied 3 = Occupied Bypass 4 = Occupied Standby | Occupied | N/A | Yes |
| Supply Fan Configuration Command | BV10104 | MV 17 | NA | NA | Inactive = Auto Active = On | Auto | N/A | Yes |
| Economizing Temperature Enable Setpoint | AV10150 Note 1 | AV 260 | NA | NA | 50.0 °F - 140.0 °F | Disabled and 63 °F | Temperature (°F or °C) | No |
| Economizing Enthalpy Enable Setpoint | AV10170 Note 1 | AV 261 | NA | NA | 19.0 to 36.0 | Disabled and 22 BTU/LB | BTU per LB | No |
| System Control Command | N/A | N/A | NA | NA | N/A | N/A | N/A | N/A |

Fault Detection and Diagnostics

The Communicating Sensor will display the following information () either at the controller user interface or through BACnet MS/TP. To view the diagnostics and fault information, navigate to the zone sensor Service View Menu screen beginning at page 1 / 7.

Table 7. Symbio 800 (SCC IPak)/700 fault detection and diagnostic

| | BACnet points / Diagnostics messages | Sensor Point | Display name / value | Range |
|----------------------------|--|---------------------------|---|---|
| Sensor Values | AI-10118 (Outdoor Air Temperature Active) | AV 101 | OA Temp | -40 to 158°F |
| | AI-10124 (Discharge Air Temperature Active) | AV 102 | DA Temp | -40 to 158°F |
| | AI-10126 (Return Air Temperature) | AV 151 | RA Temp | 32 to 209 °F |
| | AI-10125 (Mixed Air Temperature) AI-10116 Space Humidity Active AI-10120 Outdoor Air Humidity Active | AV104 AV 103 AV 152 | MA Temp RH OA RH | -40 to 150 °F 0 to 100% 0 to 100% |
| Economizer | Economizer Available: MSI-10144 (Economizer System Status) | MV 170 | Econ Available | Yes/No |
| | BI-10219 | MV 171 | 0 – Equipment Not Economizing - Inactive 1 – Equipment is Economizing - Active | Active / Inactive |
| Compressor (Cooling) | AI-10101 (Cooling Capacity Status) > 0 = Cooling ON | MV 172 | Cooling On / Off | On/Off |
| Heating (HP and Auxiliary) | AI-10102 (Heat Primary Capacity Status) > 0 = Primary Heat ON | MV 173 | Primary heat On / Off | On/Off |
| | AI-10103 (Heat Secondary Capacity Status) > 0 = Secondary Heat ON | MV 174 | Secondary heat On / Off | On/Off |
| Diagnostic | | | Unit Status | Online / Offline |
| Diagnostics See Note 5 | BI-10030 (Diagnostic: Supply Air Temp Sensor Fail) | BV 61 | SAT sensor fail | On/Off |
| | BI-10032 (Diagnostic: Outdoor Air Temperature Sensor Failed) | BV 62 | OAT sensor fail | On/Off |
| | BI-10057 (Diagnostic: Return Air Temp Sensor Fail) | BV 63 | RAT sensor fail | On/Off |
| | BI-10095(Diagnostic: Mixed Air Temp Sensor Failure) | BV 64 | MAT sensor fail | On/Off |
| Diagnostics | BI-10006 (Diagnostic: Unit Not Economizing When it Should Be) | BV 65 | Econo fail close | On/Off |
| | BI-10005 (Diagnostic: Unit Economizing When It Should Not) | BV 66 | Econo fail open | On/Off |
| | BI-10008 (Diagnostic: Outdoor Air Damper Not Modulating) | BV 67 | Block OA | On/Off |
| | BI-10007 (Diagnostic: Excessive Outdoor Air) | BV 68 | Excessive OA | On/Off |

NOTE 1

For AV10150 and AV10170, technicians should be able to enable/disable the use of these setpoints through the wall display. For clarification, page 2/4 of the Configuration Menu – Econo Enable is the economizer enable/disable configuration item.

- To enable the use of the setpoint, set the value in the wall display to In Use. This causes a BACnet value of FALSE to be written to the Out_of_Service property of the object. The Out_of_Service property should only be written to Once on change and power-up. Periodic refresh is not recommended.
- To disable use of the setpoint, set the value in the wall display to Not Used. This causes a BACnet value of TRUE to be written to the Out_of_Service property of the object. The Out_of_Service property should only be written to Once. Periodic refresh is not recommended.

This functionality is in the setup/commissioning portion of the zone sensor user interface. End users do not have access to this configuration functionality.

NOTE 2

Symbio uses a “last-in” arbitration. There is no requirement to manage the OutOfService (OOS) property from the Communicating Sensor.

NOTE 3

The following table displays the enumerated state values for the Heat Cool Mode objects.

| | |
|---------------------|--------------------|
| 1 = Auto | 9 = Emergency Heat |
| 2 = Heat | 10 = Fan Only |
| 3 = Morning Warm-up | 11 = Free Cool |
| 4 = Cool | 12 = Ice Making |
| 5 = Night Purge | 13 = Max Heat |
| 6 = Precool | 14 = Economy Mode |
| 7 = Off | 15 = Dehumidifying |
| 8 = Test | 16 = Calibrate |

NOTE 4

The occupied offset value is added or subtracted from the occupied setpoint value to calculate the heating and cooling temperature setpoints.

NOTE 5

- The technician needs a way to see the active error messages. Any active diagnostic will trigger to display bottom of main user screen the message Contact service.
- The reliability property of the object of any input sensor will be evaluated by the Communicating display to determine if the sensor is in a fault state.



Notes

Trane - by Trane Technologies (NYSE: TT), a global innovator - creates comfortable, energy efficient indoor environments for commercial and residential applications. For more information, please visit trane.com or tranetechnologies.com.

Trane has a policy of continuous product and product data improvements and reserves the right to change design and specifications without notice. We are committed to using environmentally conscious print practices.

BAS-SVP080A-EN 30 Aug 2023
Supersedes (New)

©2023 Trane