












1-
2-
3-
4-
5-
6-
7-
8-
9-
10-
11-
12-
13-
14-
15-
16-
17-
18-
19-
20-
21-
22-
23-
24-
25-
26-
27-
28-
29-
30-
31-
32-
33-
34-
35-
36-
37-
38-
39-
40-
41-
42-
43-
44-
45-
46-
47-
48-
49-
50-
51-
52-
53-
54-
55-
56-
57-
58-
59-
60-



CAUTION
USE COPPER CONDUCTORS ONLY!

UNIT TERMINALS ARE NOT DESIGNED TO ACCEPT OTHER TYPES OF CONDUCTORS.

FAILURE TO DO SO MAY CAUSE DAMAGE TO THE EQUIPMENT.

PRECAUCIÓN
N'UTILISER QUE DES CONDUCTEURS EN CUIVRE!





LES BORNES DE L'UNITÉ NE SONT PAS CONÇUES POUR RECEVOIR D'AUTRES TYPES DE CONDUCTEURS.

L'UTILISATION DE TOUT AUTRE CONDUCTEUR PEUT ENDOMMAGER L'ÉQUIPEMENT.

ATTENTION
¡UTILICE ÚNICAMENTE CONDUCTORES DE COBRE!

LAS TERMINALES DE LA UNIDAD NO ESTÁN DISEÑADAS PARA ACEPTAR OTROS TIPOS DE CONDUCTORES.

SI NO LO HACE, PUEDE OCASIONAR DAÑO AL EQUIPO.



AREA	LOCATION
1	INSIDE UNIT CONTROL BOX
2	CONDENSER SECTION
3	INSIDE SECONDARY CONTROL BOX
4	HEAT/EXTENDED CASING SECTION
5	SUPPLY FAN SECTION
6	EVAP SECTION
7	DAMPER/FILTERS SECTION
8	EXHAUST/RETURN FAN SECTION
9	EXTERNAL FIELD MTD DEVICE

REF DES	DESCRIPTION	LINE NO.
1TB3	TERM BLOCK - ELECT HT PWR DIST	84
1TB14, 1TB16	TERM BLOCK - FACTORY	40, 43, 47, 44
1TB17	TERM BLOCK - 115 VAC	48, 49, 41, 45
2TB22	TERM BLOCK - EH PWR 2-PC	53, 54, 55
4TB19	TERM BLOCK - ELECT HEAT POWER	56, 57, 58
4TB24	TERM BLOCK - ELECT HEAT CONTROLS	

REF DES	DESCRIPTION	LINE NO.
1K5	CONTACTOR - SUPPLY FAN	84
4K15-4K18	CONTACTOR - PRIMARY	40, 43, 47, 44
4K19-4K22	CONTACTOR - PRIMARY	48, 49, 41, 45
4K23-4K25	CONTACTOR - SECONDARY	53, 54, 55
4K26-4K28	CONTACTOR - SECONDARY	56, 57, 58

DEVICE DESIG	DESCRIPTION	LINE NUMBER
1S1/1TB1	UNIT DISCONN/TERM BLOCK	9
1U6	MODULE - HEAT	37
4CB10	CIRCUIT BREAKER	18
4CB11	CIRCUIT BREAKER	6
4CB12	CIRCUIT BREAKER	27
4CB13	CIRCUIT BREAKER	24
4CB14	CIRCUIT BREAKER	21
4CB7	CIRCUIT BREAKER	15
4CB8	CIRCUIT BREAKER	12
4CB9	CIRCUIT BREAKER	9
4HR7	HEATER ELEMENT ASSEMBLY	5, 8, 11, 14, 17, 20, 23, 26
4S22	SWITCH - HIGH LIMIT (DISC)	53
4S23	SWITCH - HIGH LIMIT (LINEAR)	53
5U16	V.F.D. - SUPPLY FAN	34

- NOTES:
- UNLESS OTHERWISE NOTED, ALL SWITCHES ARE SHOWN AT 25°C (77°F), AT ATMOSPHERIC PRESSURE, AT 50% RELATIVE HUMIDITY, WITH ALL UTILITIES TURNED OFF, AND AFTER A NORMAL SHUTDOWN HAS OCCURRED.
 - DASHED LINES INDICATE RECOMMENDED FIELD WIRING BY OTHERS; DASHED LINE ENCLOSURES AND/OR DASHED DEVICE OUTLINES INDICATE COMPONENTS PROVIDED BY THE FIELD. PHANTOM LINE ENCLOSURES INDICATE ALTERNATE CIRCUITRY OR AVAILABLE SALES OPTIONS. SOLID LINE INDICATES WIRING BY TRANE CO.
 - NUMBERS ALONG THE RIGHT SIDE OF THE SCHEMATIC DESIGNATE THE LOCATION OF CONTACTS BY LINE NUMBER. AN UNDERLINED NUMBER INDICATES A NORMALLY CLOSED CONTACT. AN OPEN ARROWHEAD BELOW THE LINE NUMBER POINTING UPWARD INDICATES A TIMED CONTACT WHICH BEGINS TIMING WHEN ENERGIZED.
- 4 HEATING ELEMENTS ARE SHOWN DELTA CONNECTED. ELEMENTS MAY BE WYE CONNECTED.
- 5 1K5 AND ASSOCIATED WIRING ARE PRESENT ON STANDARD UNITS (WITHOUT SUPPLY VFD) ONLY.
- 6 SEE APPLICABLE VARIABLE FREQUENCY DRIVE SCHEMATIC FOR BALANCE OF CIRCUIT.

WARNING
HAZARDOUS VOLTAGE!
DISCONNECT ALL ELECTRIC POWER INCLUDING REMOTE DISCONNECTS AND FOLLOW LOCK OUT AND TAG PROCEDURES BEFORE SERVICING. INSURE THAT ALL MOTOR CAPACITORS HAVE DISCHARGED STORED VOLTAGE. UNITS WITH VARIABLE SPEED DRIVE, REFER TO DRIVE INSTRUCTIONS FOR CAPACITOR DISCHARGE.

AVERTISSEMENT
TENSION DANGEREUSE!
COUPER TOUTES LES TENSIONS ET OUVRIR LES SECTIONNEURS À DISTANCE. PUIS SUIVRE LES PROCÉDURES DE VERROUILLAGE ET DES ÉTIQUETTES AVANT TOUTE INTERVENTION. VÉRIFIER QUE TOUS LES CONDENSATEURS DES MOTEURS SONT DÉCHARGÉS. DANS LE CAS D'UNITÉS COMPORTANT DES ENTRAÎNEMENTS À VITESSE VARIABLE, SE REPORTER AUX INSTRUCTIONS DE L'ÉNTRAÎNEMENT POUR DÉCHARGER LES CONDENSATEURS.

ADVERTENCIA
¡VOLTAJE PELIGROSO!
DESCONECTE TODA LA ENERGÍA ELÉCTRICA, INCLUIDO LAS DESCONEXIONES REMOTAS Y SIGA LOS PROCEDIMIENTOS DE CIERRE Y ETIQUETADO ANTES DE PROCEDER AL SERVICIO. ASEGÚRESE DE QUE TODOS LOS CAPACITORES DEL MOTOR HAYAN DESCARGADO EL VOLTAJE ALMACENADO. PARA LAS UNIDADES CON EJE DE DIRECCIÓN DE VELOCIDAD VARIABLE, CONSULTE LAS INSTRUCCIONES PARA LA DESCARGA DEL CONDENSADOR.

EL NO REALIZAR LO ANTERIORMENTE INDICADO, PODRÍA OCASIONAR LA MUERTE O SERIAS LESIONES PERSONALES.

TRANE A DIVISION OF AMERICAN STANDARD, INC. THIS DRAWING AND ALL RIGHTS RESERVED. NO PARTS OR ITS CONTENTS DISCLOSED TO OUTSIDE PARTIES WITHOUT THE CONSENT OF TRANE. DRAWN BY: K. RYAN REVISION DATE: 2/16/07 @DATE: 12-07-06 100kW - 460V/60HZ AND 575V/60HZ	FILE NUMBER: 2309-3660 DRAWING NUMBER: 1 OF 1 REV B
--	--