

- NOTES:
1. ALL WIRING AND DEVICES SHOWN DASHED TO BE SUPPLIED AND INSTALLED BY THE CUSTOMER IN ACCORDANCE WITH LOCAL AND NATIONAL ELECTRICAL CODES.
 2. IF ANY OF THE ORIGINAL WIRE, AS SUPPLIED WITH THIS UNIT, MUST BE REPLACED, REPLACE IT WITH APPLIANCE WIRING MATERIAL RATED AT 105°C.
 3. THREE PHASE MOTORS ARE PROTECTED UNDER PRIMARY SINGLE PHASING CONDITIONS. ALL MOTORS HAVE INTERNAL OVERLOAD PROTECTION. COMPRESSORS HAVE INTERNAL THERMAL PROTECTION.
 4. CONNECTIONS SHOWN ARE FOR 230V/60HZ/3PH. WHEN 208V/60HZ/3PH OR 200V/50HZ/3PH OPERATION IS REQUIRED, REMOVE WIRES FROM 230V TERMINAL ON TNS3 AND CONNECT TO 208V TERMINAL ON TNS3.
 5. CONNECTIONS SHOWN ARE FOR 230V/60HZ/3PH. WHEN 208V/60HZ/3PH OPERATION IS REQUIRED, REMOVE WIRES FROM 230V TERMINAL ON TNS1 AND CONNECT TO 208V TERMINAL ON TNS1.
 7. WHEN COMM INTERFACE IS INSTALLED, CONNECT CABLE P21 TO COMM J1 AND P14 TO RTRM J4. SEE INSET A. SEE COMM INTERFACE LITERATURE FOR SWITCH SETTINGS.
 8. WIRES W1, W2 AND W3 USED WITH ELECTRIC HEAT OPTION ONLY. WHEN ELECTRIC HEAT IS REQUIRED REMOVE WIRE NUT FROM WIRES AND CONNECT TO HI VOLTAGE TERMINAL BLOCK (HTB1) PER DIAGRAM. SEE ELECTRIC HEAT DIAGRAM FOR REMAINDER OF CIRCUIT.

14. CONNECT PPF5 TO COMM IF PRESENT. IF RTOM OR ECONOMIZER W/ COMM INTERFACE IS INSTALLED, CONNECT PPF5 TO J2 ON COMM. IF COMM INTERFACE IS NOT INSTALLED, CONNECT PPF5 TO J4 ON RTRM. SEE INSET B.
15. REQUIRED FOR CO2 OR VENTILATION OVERRIDE ACCESSORY.
16. TO DISABLE COMPRESSORS, REMOVE JUMPER AND CONNECT FIELD SUPPLIED CONTROL DEVICE.
17. TO SHUT DOWN THE UNIT FOR EMERGENCY STOP, REMOVE JUMPER AND INSTALL FIELD SUPPLIED DEVICE.
23. CONNECT WIRES 36BY AND 36BZ TO ENABLE 3 STAGE COOLING ONLY ON HIGH EFFICIENCY SHORT ORIFICE UNITS.
24. TITLE 24 ONLY
25. SINGLE ZONE VAV ONLY
26. TITLE 24 AND SINGLE ZONE VAV
27. F CONTACTOR USED FOR CV UNITS. FOR TITLE 24/SINGLE ZONE VAV UNITS REPLACE F WITH HTB3.
28. IF OPTIONAL ECONOMIZER IS ORDERED WITHOUT RTOM, CONNECT PPM6 TO PPF8. SEE INSET C.
29. WIRING SHOWN IS FOR CV UNITS. 36W NOT PRESENT ON VAV UNITS.
30. WIRE NUMBERS WITH A "V" IN BETWEEN ARE CV/VAV OPTIONS.

WIRE COLOR DESIGNATION	WIRE COLOR DESIGNATION
ABBR	COLOR
BK	BLACK
BL	BLUE
BR	BROWN
GR	GREEN
OR	ORANGE
PR	PURPLE
RD	RED
WH	WHITE
YL	YELLOW
TN	TAN

FUSE REPLACEMENT TABLE
FU1, FU2
208-230V
TYPE FLG
20 AMP

IMPORTANT!
DO NOT ENERGIZE UNIT UNTIL CHECK-OUT AND START-UP PROCEDURE HAS BEEN COMPLETED.

TRANE	
THIS DRAWING IS PROPRIETARY AND SHALL NOT BE COPIED OR ITS CONTENTS DISCLOSED TO ANY OTHER PARTIES WITHOUT THE CONSENT OF TRANE.	
DRAWN BY: D. SHANNON	TRANE DATE: 10-17-11
REPLACES:	REVISION DATE: 11-11-11
CAD SYSTEM USED: PRO/DETAIL	SIMILAR TO: 2313-0044-B

FILE NUMBER: 2313-1429	DRAWING NUMBER: 2313-1402	SHEET: 1 OF 1	REV: B
VOYAGER 2			
DIAGRAM			
CONNECTIONS - CONTROL BOX			
HEAT PUMP/ELECTRIC HEAT - 208-230 VAC			
W/ TITLE 24/SINGLE ZONE VAV			
WC 200, 240			

CAUTION

USE COPPER CONDUCTORS ONLY!

UNIT TERMINALS ARE NOT DESIGNED TO ACCEPT OTHER TYPES OF CONDUCTORS.

FAILURE TO DO SO MAY CAUSE DAMAGE TO THE EQUIPMENT.

PRECAUCIÓN

N'UTILISER QUE DES CONDUCTEURS EN CUIVRE!

LES BORNES DE L'UNITÉ NE SONT PAS CONÇUES POUR RECEVOIR D'AUTRES TYPES DE CONDUCTEURS.

L'UTILISATION DE TOUT AUTRE CONDUCTEUR PEUT ENDOMMAGER L'EQUIPEMENT.

ATTENTION

¡UTILICE ÚNICAMENTE CONDUCTORES DE COBRE!

LAS TERMINALES DE LA UNIDAD NO ESTÁN DISEÑADAS PARA ACEPTAR OTROS TIPOS DE CONDUCTORES.

SI NO LO HACE, PUEDE OCASIONAR DAÑO AL EQUIPO.

