



CONDENSER SECTION


INSET 3A - CONDENSER FAN MOTORS




105T-130T ONLY




INSET 3B - COMPRESSORS




INSET 3F - SATURATED CONDENSING TEMP SENSORS




INSET 3D - OPTIONAL HOT GAS BYPASS SOLENOID VALVE



INSET 3E - HIGH AND LOW PRESSURE CUTOUPS



INSET 3C - CONVENIENCE OUTLET



DEVICE PREFIX	LOCATION CODE
AREA	LOCATION
1	INSIDE UNIT CONTROL BOX
2	CONDENSER SECTION
3	AIR HANDLER SECTION
4	HEATING SECTION
5	EXTERNAL FIELD MOUNTED DEVICE

IMPORTANT!

DO NOT ENERGIZE UNIT UNTIL CHECK-OUT AND START-UP PROCEDURE HAS BEEN COMPLETED.

CAUTION

USE COPPER CONDUCTORS ONLY!

UNIT TERMINALS ARE NOT DESIGNED TO ACCEPT OTHER TYPES OF CONDUCTORS.

FAILURE TO DO SO MAY CAUSE DAMAGE TO THE EQUIPMENT.

ATTENTION

N'UTILISER QUE DES CONDUCTEURS EN CUIVRE!

LES BORNES DE L'UNITÉ NE SONT PAS CONÇUES POUR RECEVOIR D'AUTRES TYPES DE CONDUCTEURS.

L'UTILISATION DE TOUT AUTRE CONDUCTEUR PEUT ENDOMMAGER L'EQUIPEMENT.

PRECAUCIÓN


¡UTILICE ÚNICAMENTE CONDUCTORES DE COBRE!

LAS TERMINALES DE LA UNIDAD NO ESTÁN DISEÑADAS PARA ACEPTAR OTROS TIPOS DE CONDUCTORES.


SI NO LO HACE, PUEDE OCASIONAR DAÑO AL EQUIPO.

AIR HANDLER SECTION


INSET 3AB - SUPPLY AIR FAN MOTORS



INSET 3Z - SUPPLY AIR TEMP SENSOR




INSET 3AA - FILTER SWITCH




INSET 3P - AIRFLOW PROVING SWITCHES




INSET 3AC - EXHAUST FAN MOTOR




INSET 3L - SOLENOID CHARGE ISOLATION CKT #1




INSET 3M - SOLENOID CHARGE ISOLATION CKT #2




INSET 3G - LEAVING EVAP TEMP SENSORS




INSET 3J - ENTERING EVAP TEMP SENSORS




INSET 3AB - VENTILATION CONTROL MODULE




INSET 3S - OUTDOOR AIR TEMP/HUMIDITY SENSORS




INSET 3T - RETURN AIR TEMP/HUMIDITY SENSORS




INSET 3K - HIGH DUCT TEMP T-STAT




INSET 3AE - FINAL FILTER SWITCH



INSET 3V - ECONOMIZER ACTUATOR




EXHAUST FAN CONTROL




HEAT SECTION


INSET 4F - 2-STAGE NATURAL GAS HEAT




INSET 4H - MODULATING NATURAL GAS HEAT




INSET 4B15



INSET 4J - ELECTRIC HEAT



INSET 3Y - STEAM OR HOT WATER HEAT



INSET 3AE - EXHAUST FAN VARIABLE FREQUENCY DRIVE

