Installer's Guide

Replacement Compressor Brazed-in Reciprocating 1.5 - 3 Ton Units

ALL phases of this installation must comply with NATIONAL, STATE AND LOCAL CODES

IMPORTANT — This Document is customer property and is to remain with this unit. Please return to service information pack upon completion of work.

WARNING

This information is for use by individuals having adequate backgrounds of electrical and mechanical experience. Any attempt to repair a central air conditioning product may result in personal injury and/or property damage. The manufacturer or seller cannot be responsible for the interpretation of this information, nor can it assume any liability in connection with its use.

A CAUTION

Base Pan Damage!


These are recommended procedures for the replacement of brazed-in compressors. Failure to follow these procedures can cause damage to the base pan.

Note: Taller cabinet sizes may require the removal of the coil to provide safe access to the compressor.


Installation

Step 1 - Recover refrigerant. After completing evacuation procedure, open refrigerant gauges to ensure system remains at zero psi. Remove top from unit.

Step 2 - Locate discharge line and cut with tubing cutter in the middle of the first vertical section coming from compressor.



Step 3 - Place shield or wet cloth on base to prevent damage from heat or molten alloy. Unbraze suction tube at the compressor stub.




© 2011 Trane 07/11

Installer's Guide


Step 4 - Remove compressor mounting bolts, disconnect wiring at compressor header and lift compressor out.

Step 5 - Set replacement compressor on suitable surface outside of unit cabinet.

Step 6 - Install included "L" tube per illustration. Align towards suction stub and braze. **Allow to cool.**



- **Step 7** Set replacement compressor into unit and reinstall bolts.
- Step 8 Braze discharge line from unit into "L" tube.
- Step 9 Braze suction tube and connect wiring.
- **Step 10 -** Complete replacement process following evacuation and charging procedures.



The manufacturer has a policy of continuous product and product data improvement and it reserves the right to change design and specifications without notice.