



- ⚠ WARNING**

CAUTION

ATTENTION

PRECAUCIÓN

AVERTISSEMENT

⚠️ ADVERTENCIA
¡VOLTAJE PELIGROSO!

DESCONECTE TODA LA ENERGÍA ELÉCTRICA, INCLUSO LAS DESCONEXIONES REMOTAS Y SIGA LOS PROCEDIMIENTOS DE CIERRE Y ETIQUETADO ANTES DE PROCEDER AL SERVICIO. ASEGURESE DE QUE TODOS LOS CAPACITORES DEL MOTOR HAYAN DESCARGADO EL VOLTAJE ALMACENADO. PARA LAS UNIDADES CON EJE DE DIRECCIÓN DE VELOCIDAD VARIABLE, CONSULTA LAS INSTRUCCIONES PARA LA DESMONTAJE DEL CONDENSADOR. EL NO REALIZAR LO ANTERIORMENTE INDICADO, PODRÍA OCASIONAR LA MUERTE O SERIAS LESIONES PERSONALES.

REPLACEMENT FUSE SIZES						
FUSE PROTECTION FUNCTION	UNIT SIZE	UNIT VOLTAGE	DESIGNATION	VOLTS	CLASS	AMPS
CONDENSER FANS	ALL	200/60	1F1-1F12/2F1-2F12	60		10
	ALL	230/60				10
	ALL	380/60				5
CONTROL POWER TRANSFORMER - PRIMARY	250 TON	440/60	1F13,1F14/2F13,2F14	600	CC	5
	thru	575/60				10
	thru	400/50				4
CONTROL POWER TRANSFORMER - 115V SECONDARY	500 TON	ALL	1F15/2F15			10
CONTROL POWER TRANSFORMER - 24V SECONDARY		ALL	1F16-17/2F16-17			30
INVERTER DRIVE AND/OR INVERTER TRANSFORMER - PRIMARY		ALL BUT 575/60	1F18-1F23/2F18-2F23			6-25