



Installation Sheet

Registering Trane® Controls Software

You can register both Tracer Summit™ and Rover™ software online.

Note: *Tracer Summit software must be registered within 30 days from installation. However, you can use the software in demo mode for up to 30 days. After the demo period is over, you must register the software to continue to use it. Rover Service Tool software must be registered immediately.*

Registering the software

To register either Tracer Summit or Rover software, each PC workstation requires a unique authorization code that is found on the Rover product USB flash drive or the Tracer Summit compact disk (CD) case.

Note: *The product USB flash drive should only be used to install the Rover software.*

Registering Online

Before you begin, make sure you have the unique authorization code.

To register online:

1. Install the Trane Controls software.

Note: *On the same PC, make sure that the Internet connection is active. (To register from another PC, refer to the following the note under Step 5.)*

2. Start the software you want to register.
3. In the **Tracer Summit Welcome** dialog box, click the **Register Now** button. For **Rover**, click the **Registration** button, then click the **Register Additional Options** button.
4. Select the option to register over the Internet, then click **Next**.
5. Select **Register** this PC, then click **Next** and continue as instructed at the Trane Product Registration Web site.

3270 3380 G

SAFETY WARNING

Only qualified personnel should install and service the equipment. The installation, starting up, and servicing of heating, ventilating, and air-conditioning equipment can be hazardous and requires specific knowledge and training. Improperly installed, adjusted or altered equipment by an unqualified person could result in death or serious injury. When working on the equipment, observe all precautions in the literature and on the tags, stickers, and labels that are attached to the equipment.

Note: To register from a different PC, first obtain the locking code from the PC to be registered. From a PC with an Internet connection, go to the Web site www.basregistration.trane.com and follow the online instructions. Copy the license code generated at the Web site to the PC with the software to be registered.

Registering When in Demo Mode or After Installing Additional Options

At any time, you can register the software or additional options.

In Tracer Summit

Note: In Tracer Summit the demo period lasts 30 days from installation.

1. On the Help menu, click **About Tracer Summit**.
2. In the About Tracer Summit dialog box, click **Register Additional Options** (register online or offline as instructed above).

In Rover:

Note: Rover Service Tool software must be registered immediately.

1. Start Rover.
2. Click the **Registration** button.
3. Click the **Register Additional Options** button (register online or offline as instructed above).

Verifying Registered Options

You can check to see which options are registered for Trane Controls software.

In Tracer Summit:

1. On the Help menu, click **About Tracer Summit**.
2. Click the **View Registered Options** button.

In the Registered Options Dialog box, an X appears in front of each registered option.

In Rover:

Start Rover. The Rover Service Tool Main Menu dialog box appears. If the buttons and descriptions appear gray, Rover is not registered.

When to Re-register

You must re-register the software when you:

- Replace an existing PC workstation with a new one
- Upgrade the PC operating system
- Replace the PC workstation hard drive

The authorization code must be reset before you can re-register the software. Contact the local Trane office to have the authorization code reset.

Note: Tracer Summit software does not need to be re-registered after uninstalling and then reinstalling it. The registration remains valid because the registration information is stored separately on the hard drive and is not removed during the uninstall.

Registration Codes

For Tracer Summit Version 13 and higher, the registration system is based on three codes:

- **Authorization code:** the software serial number found on the product USB flash drive. This code is required for each PC workstation to obtain future upgrades and customer support. When upgrading from Tracer Summit Version 13 and higher, use the authorization code on the product CD case. When upgrading an earlier version and up to Version 12, use the software serial number. Both codes start with an *E*.
- **Locking code:** a number unique to the PC. You can find it on the registration screens or by clicking About Tracer Summit on the Help menu.
- **License code:** a unique number based on the locking code and the authorization code. For Version 12 and earlier, it was called the registration number. This code is automatically generated during the registration process.

Keep the authorization code. It is required for upgrades and customer service support. The first five digits of the authorization code indicates the type of software package. The following table lists software packages and corresponding authorization codes.

Table 1. Authorization codes by product

Software package	Code prefix
Rover Comm4 software and hardware	E0502
Rover LonTalk software and hardware	E0456
Rover LonTalk configuration only	E0503
Rover complete	E0501
Rover test and balance	E0517
Rover software upgrade	E1199
Rover complete tool kit	E1196
Rover LonTalk configuration only	E1192
Rover Comm4	E1191
Rover LonTalk	E1121
Tracer Summit base	E1111
Tracer Summit base upgrade (requires a previous authorization code)	E1113
Tracer Summit + Critical Control System add-on	E1148
Tracer Summit + Tracer 100/Tracker Communication add-on package	E1150
Tracer Summit + Building Management add-on	E1152
Tracer Summit + Enterprise Management add-on	E1154
Critical Control System add-on	E1149
Tracer 100/Tracker Communication add-on	E1151
Building Management add-on	E1153
Enterprise Management add-on	E1155

Trane - by Trane Technologies (NYSE: TT), a global climate innovator - creates comfortable, energy efficient indoor environments for commercial and residential applications. For more information, please visit trane.com or tranetechnologies.com.

Trane has a policy of continuous product and product data improvement and reserves the right to change design and specifications without notice. We are committed to using environmentally conscious print practices.