

Service Parts Installation Instructions

## **Replacing the Enclosure Back**

For the Tracer<sup>™</sup> AH541/MP581 or the Tracer

Summit™ BMTX BCU

Order Number: S3090-0353-62

Overview
The replacem

**A** WARNING

**A** CAUTION

**NOTICE** 

The replacement enclosure back is shipped with replacement parts needed for re-installing the termination board and power-supply assembly into the enclosure back. Table 1 lists the parts; Figure 1 illustrates them. Figure 2 shows their location on the enclosure.

Indicates a potentially hazardous situation

Indicates a potentially hazardous situation

Indicates a situation that could result in equipment or property-damage only accidents.

which, if not avoided, could result in death or

which, if not avoided, could result in minor or moderate injury. It could also be used to alert

The three types of advisories are defined as follows:

serious injury.

X39641206-01

## A SAFETY WARNING

Only qualified personnel should install and service the equipment. The installation, starting up, and servicing of heating, ventilating, and air-conditioning equipment can be hazardous and requires specific knowledge and training. Improperly installed, adjusted or altered equipment by an unqualified person could result in death or serious injury. When working on the equipment, observe all precautions in the literature and on the tags, stickers, and labels that are attached to the equipment.

May 2020

BAS-SVN064C-EN
© 2020 Trane

12VNE

Way 2020

Table 1. Maximum drop by unit width

Figure 1 Reference	Item	Qty	Location	Part Description	Part Number
А	Screw	5	Transformer Terminal block Transformer cover (small) Transformer cover (large)	M4 X 8	33025002
В	Screw	1	Ground	10-32 x 1/2'	X25020713010
С	Screw	1	Electric Chassis	M3.5 x 12	33024004
D	Cable Holder	1	Enclosure Block		33016071
E	Label	1	Enclosure Block	Warning Label	X39002583010B

To install the replacement enclosure back, refer to Figure 2. If the replacement Warning label is needed (part E), apply it over the existing warning label (not shown in Figure 2).

## **▲** WARNING

## Hazardous Voltage!

Before making electrical connections, lock open the supply-power disconnect switch. Failure to do so may cause death or serious injury.

For detailed instructions on wiring the transformer, see *Installation Instruction 3270 3383*, *Installing the Tracer Summit BMTX Building Control Unit.* 


3

Figure 1. Illustration of replacement parts










F



Figure 2. Replacement part locations



Trane - by Trane Technologies (NYSE: TT), a global climate innovator - creates comfortable, energy efficient indoor environments for commercial and residential applications. For more information, please visit trane.com or tranetechnologies.com.

Trane has a policy of continuous product and product data improvement and reserves the right to change design and specifications without notice. We are committed to using environmentally conscious print practices.