



2 CONNECT CUSTOMER SUPPLIED DEVICE TO VHR-TB FOR VENTILATION HEAT OPERATION.
VHR RELAY IS ACTIVE WHEN UNIT IS IN HEAT MODE.
ELECTRICAL RATING FOR VHR CONTACTS: 3A @ 277VAC

PRECEDENT
UNIT SCHEMATIC

SCHEMATIC; SHEET 4, CONTROLS,
ADAPTER BOARD UNIT CONTROLS, DUAL
COMPRESSOR, SINGLE VS OUTDOOR FAN

MASTER NUMBER:	DRAWING NUMBER:	SHEET:	REV
	12134963	4	B