




IMPORTANT!
DO NOT ENERGIZE
UNIT UNTIL CHECK-OUT
AND START UP PROCEDURE
HAS BEEN COMPLETED



DEVICE PREFIX LOCATION GUIDE	
AREA	LOCATION
1	INSIDE UNIT CONTROL BOX
2	CONDENSER SECTION
3	AIR HANDLER SECTION
4	HEATING SECTION
5	EXTERNAL FIELD MOUNTED DEVICE



A DIVISION OF ATLANTA STANDARD INC. ALL RIGHTS RESERVED	
THIS DRAWING IS INCOMPLETE AND SHALL NOT BE COPIED OR ITS CONTENTS DISCLOSED TO ANYONE OTHER THAN THE WRITTEN CONSIGNEE OF THESE	
DRAWN BY: P. BRUCE JR.	DATE: 08/01/00
REPLACES:	REVISION DATE:
CAD055	SIMILAR TO: 2307-4576

