

4 WIRING SHOWN IS FOR 460V OR 380V. FOR 575V MOVE ALL WIRES FROM H2 TERMINAL TO H3 TERMINAL ON TNS3. FOR 415 V MOVE ALL WIRES FROM H2 TERMINAL TO H3 TERMINAL ON TNS3.

12 FUSE FU20, FU21 AND SWITCH SRD ARE USED FOR OPTIONAL FACTORY POWER CONVENIENCE OUTLET. WIRES 400A AND 401A ARE CONNECTED TO FACTORY SUPPLIED DISCONNECT SWITCH.

TRANSE THIS DRAWING IS PROPRIETARY AND SHALL NOT BE COPIED OR ITS CONTENTS DISCLOSED TO OUTSIDE PARTIES WITHOUT THE CONSENT OF TRANSE.		FILE NUMBER: 2309-3453	DRAWING NUMBER: 2309-3461	SHEET: 1 OF 1	REV A
DRAWN BY: D. GOUTAM		TRANSE DATE: 11-30-07	VOYAGER 3		
REPLACES:		REVISION DATE:	CONTROL BOX CONNECTION FOR YC 40-50 TON LO HEAT 380-575 VOLT CONSTANT VOLUME		
EAD SYSTEM USED: 2307-4687		SIMILAR TO:			

IMPORTANT!
DO NOT ENERGIZE UNIT
UNTIL CHECK-OUT AND
START-UP PROCEDURE HAS
BEEN COMPLETED.

