

12 FUSE FU20, FU21 AND SWITCH SRD ARE USED FOR OPTIONAL FACTORY POWER CONVENIENCE OUTLET. WIRES 400A AND 401A ARE CONNECTED TO FACTORY SUPPLIED DISCONNECT SWITCH.

SI NO LO HACE, PUEDE OCASIONAR DAÑO AL EQUIPO.

METAL PLATE 11 X 17

VOYAGER 3
CONTROL BOX CONNECTION
YC 50 TON LO HEAT 380-575 VOLT
CONSTANT VOLUME

