



- 1 JUMPER BETWEEN 1T16-13 AND 1T16-14 REQUIRED FOR 2-STAGE NATURAL GAS HEAT (<100 MBH) OR ELECTRIC HEAT ONLY.
- 2 1T17 AND ASSOCIATED WIRING REQUIRED WITH OPTIONAL GBAS 0-5V MODULE ONLY.
- 3 1T18 AND ASSOCIATED WIRING REQUIRED WITH OPTIONAL GBAS 0-10V MODULE ONLY.
- 4 REMOVE JUMPER BETWEEN 1T13-23 AND 1T13-24 WHEN HIGH DUCT TEMP T-STAT (4517 & 8517) IS ORDERED.
- 5 1F25, 1F26, AND 1S8 AND ASSOCIATED WIRING REQUIRED FOR CONVENIENCE OUTLET OPTION ONLY.
- 6 WIRES 1A8, 2A8 AND 3A8 ARE ONLY REQUIRED FOR SPECIFIC ELECTRIC HEATER CONFIGURATIONS. SEE APPLICABLE HEATER SCHEMATIC.
- 7 REMOVE JUMPER BETWEEN 1T14-15 AND 1T14-16 WHEN A REMOTE EMERGENCY STOP SWITCH IS USED.
- 8 1T129 NOT AVAILABLE WHEN BOTH 0-5V GBAS AND 0-10V GBAS ARE INSTALLED. IF A SINGLE GBAS IS INSTALLED, 1T129 WILL OCCUPY THE POSITION WHERE THE TERMINAL BLOCK SUPPORTING THE SECOND GBAS WOULD BE PLACED. (SEE INSET 1A)
- 9 CIRCUIT BREAKERS CB1, CB2, CB3 & CB4 MUST CONNECT TO COLORED AUX CONTACT WIRES BLUE/LEAD (COM) AND YEL (N) WHEN SHORT CIRCUIT WITHSTAND RATING (SCWR) IS CHOSEN AS AN OPTION.
- 10 FOR RETURN FAN INSTALL JUMPER BETWEEN 1T13-11 & 1T13-12. FOR EXHAUST FAN PROVIDED, INSTALL WIRES 5A8B, AND 5A1B.

