

Return Air / Service Wall Panel

For Air Handler Models
TMM4, TMM5


Return Air / Service Wall Panel - BAYTMMWALLPNL1

FEATURES

- FRAMED, LOUVERED PANEL FOR WALL MOUNT APPLICATIONS
- BAYTMMWALLPNL1 INCLUDES ACCESS PANEL FRAME AND ACCESS PANEL
- WHITE FINISH
- ACCESS PANEL FRAME MOUNTS EASILY TO WALL

Installation Instructions

1. Ensure there is a structural frame to mount the sheet metal frame. See the frame rough opening dimensions.
2. Secure the metal frame to the wall using the (8) #10-1¼” screws provided. The frame should be oriented with the clips at the top of the frame.
NOTE: Do not use the 1 ¼ “ long screws in the holes with clips.
3. Place the tabs of the louvered panel into the bottom slots of the frame.
4. Secure the louvered panel to the frame using the (2) #10- ¾” white screws provided.



BAYTMMWALLPNL1

All Dimensions in Inches	Frame Outer Dimensions		Frame Rough Opening Dimensions		Air Handler Models	Style
	W	H	W	H		
BAYTMMWALLPNL1	25.81	46.81	22.81	43.81	TMM4 TMM5	Louvered

About Trane and American Standard Heating and Air Conditioning

Trane and American Standard create comfortable, energy efficient indoor environments for residential applications. For more information, please visit www.trane.com or www.americanstandardair.com

The manufacturer has a policy of continuous data improvement and it reserves the right to change design and specifications without notice. We are committed to using environmentally conscious print practices.