

# Return Air / Service Wall Panel

For Air Handler Models  
GMU2 / GMV2


## Return Air / Service Wall Panel - BAYTGM1WALLPNL

### FEATURES

- FRAMED, LOUVERED PANEL FOR WALL MOUNT APPLICATIONS
- BAYTGM1WALLPNL INCLUDES ACCESS PANEL FRAME AND ACCESS PANEL
- WHITE FINISH
- ACCESS PANEL FRAME MOUNTS EASILY TO WALL

### Installation Instructions

1. Ensure there is a structural frame to mount the sheet metal frame. See the frame rough opening dimensions.
2. Secure the metal frame to the wall using the (8) #10-1¼" screws provided. The frame should be oriented with the clips at the top of the frame.  
NOTE: Do not use the 1 ¼ " long screws in the holes with clips.
3. Place the tabs of the louvered panel into the bottom slots of the frame.
4. Secure the louvered panel to the frame using the (2) #10- ¾" white screws provided.



BAYTGM1WALLPNL

All Dimensions in Inches	Frame Outer Dimensions		Frame Rough Opening Dimensions		Air Handler Models	Style
	W	H	W	H		
BAYTGM1WALLPNL	25.76	44.29	22.88	43.88	GMU2 GMV2	Louvered

### About Trane and American Standard Heating and Air Conditioning

Trane and American Standard create comfortable, energy efficient indoor environments for residential applications. For more information, please visit [www.trane.com](http://www.trane.com) or [www.americanstandardair.com](http://www.americanstandardair.com)

The manufacturer has a policy of continuous data improvement and it reserves the right to change design and specifications without notice. We are committed to using environmentally conscious print practices.