



Setting Up the Trane 3-Heat/2-Cool or 1-Heat/1-Cool Thermostat

Contents

- Set the system mode
- Set the fan mode
- Change the temperature setpoint

i More information:
<https://www.trane.com/stat>

© 2009 Trane All rights reserved
X39641170-01A

1-Heat/1-Cool:
X13511535-01
BAYSTAT151A
THT02772

3-Heat/2-Cool:
X13511536-01
BAYSTAT155A
THT02773

To set the system mode:

1. Press . The current mode flashes.
2. Press or to select a mode.
3. Tap or wait 5 seconds to save and exit.

(Emergency/Aux. Heat)

(Heat)

(Cool)

(Heat/Cool) AUTO

(Off) OFF

Notes: Depending upon the thermostat model, system type, and changeover setting selected during installer configuration, some of the system modes may be absent. Refer to the installation instructions for more information.

To set the fan mode:

1. Press . The current mode flashes.
2. Press or to select a mode.
3. Tap or wait 5 seconds to save and exit.

(On)

AUTO

Note: Depending upon the system type and fan control option selected during installer configuration, you may be unable to change the fan mode. Refer to the installation instructions for more information.

To change the temperature setpoint:

1. Set the system to the mode you want to change.
2. Press or one time to show the current setpoint.
3. Within 5 seconds, press to raise the setpoint or to lower the setpoint.
4. Press or to change between Heat or Cool setpoint, if Heat/Cool is enabled.
5. Tap or wait 5 seconds to save and exit.

78 °F
Auto

72 °F
Auto

(Cooling)

(Heating)