TRANE DATE: 24-FFB-2022 23094869 7/2/4/13 ® THE FIELD PROVIDED INDICATORS MAY BE RELAYS, LIGHTS OR AUDIBLE DEVICES. MASTER FILE: FIELD SELECTABLE AS: CONDENSER PRESSURE, DELTA PRESSURE OR CONTROL OUTPUT SIGNAL FOR CONDENSER HEAD PRESSURE CONTROL. DASHED LINES INDICATE FIELD WIRING BY OTHERS. PHANTOM LINES INDICATE ALTERNATE CIRCUITRY OR AVAILABLE SALES OPTIONS. CHECK SALES ORDER TO DETERMINE IF WIRING IS REQUIRED FOR DETERMINE OF THE WIRING IS REQUIRED. EACH FUNCTION IS ASSOCIATED WITH A SPOT RELAY. THE INDICATORS MAY BE CONNECTED TO EITHER OR BOTH OF THE NORMALLY OPEN OR NORMALLY CLOSED RELAY CONTACTS OF EACH OF THE 4 SPOT RELAYS ON THE OPTIONAL UNIT OPERATING STATUS MODULE. REVISION DATE FIELD LAYOUT DIAGRAM DO NOT RUN LOW VOLTAGE CONTROL WIRING (30 VOLTS OR LESS) IN IN CONDUIT WITH 110 VOLT OR HIGHER WIRING. DO NOT EXCEED THE FOLLOWING MAXIMUM RUN LENGTHS FOR A GIVEN SIZE: 14 AWG, 5000 FT; 18 AWG, 1000FT REPLACES: **RTHD** SIMILAR TO AND SHALL NOT BE COPIED THE FUNCTIONS OF THE OPERATING STATUS MODULE RELAYS ARE PROGRAMABLE 2 REQUIRED DEVICE AND/OR CIRCUITRY BY OTHERS. OR ITS CONTENTS DISCLOSED SEE IOM FOR DETAILS. DEFAULT FUNCTIONS ARE SHOWN. TO OUTSIDE PARTIES WITHOUT REQUIRED DEVICE AVAILABLE FROM TRANE. FIELD INSTALLED THE CONTACTS FOR THESE FEATURES ARE JUMPERED AT THE FACTORY THE NORMALLY OPEN CONTACTS ON EACH RELAY OPERATE AS FOLLOWS THE COMMON TO MINESE PERIODES AND SOMEPHED AT THE PARTON OF THE SET OF THE PROPERTY OF THE MOST OF THE MOST OF THE MOST OF THE DESIRED REMOVE THE NOTED JUMPERS AND CONNECT TO THE DESIRED CONTROL CIRCUIT. USED BY: OPENING THE EXTERNAL AUTO-STOP CONTACT WILL INITATE A SHUT DOWN SEQUENCE OF THE CHILLER. CLOSURE OF THE CONTACT WILL ALLOW THE CHILLER TO RETURN TO NORMAL AUTOMATIC OPERATION. COMPRESSOR — THE NO CONTACTS CLOSE WHEN COMPRESSOR STATUS RUNNING FROM STARTER MODULE IS EITHER STARTING OR RUNNING. CAD: CREO SCHEMATICS THE NO CONTACTS OF OSE WHEN THERE IS AN DIAGNOSTIC FIELD PROVIDED 115 VOLT 60HZ OR 220 VOLT 50HZ CONTROL POWER SUPPLIES ARE REQUIRED. THE MAX FUSE SIZE FOR ALL FIELD PROVIDED THE NO CONTACTS CLOSE WHEN THERE IS AN DIAGNOS.
THAT HAS CAUSED A CHILLER SHUTDOWN WITH EITHER
A MANUAL RESET REQUIRED OR AN AUTOMATIC RESET AN OPENING OF THE EMERGENCY STOP CONTACT WILL SHUT THE CHILLER DOWN IMMEDIATELY AND TRIGGER AN EMERGENCY STOP INPUT DIAGNOSTIC. CLOSURE OF THE CONTACT AND A MANUAL RESET OF THE UNIT CONTROL DIAGNOSTIC WILL ALLOW WIRING IS 15 AMPS. GROUND ALL CUSTOMER PROVIDED POWER SUPPLIES AS REQUIRED BY CODE. GREEN GROUND SCREWS ARE PROVIDED IN UNIT THE NO CONTACTS CLOSE WHENEVER THE CHILLER HAS BEEN RUNNING IN ONE OF THE UNLOADING TYPES OF LIMIT MODES (CONDENSER, EVAPORATOR, CURRENT LIMIT THE CHILLER TO RETURN TO NORMAL OPERATION **↑** WARNING CLOSED CONTACT COMMANDS BASE LOADING OPERATION CAUTION HASE IMBALANCE LIMIT) CONTINUOUSLY FOR THE HAZARDOUS VOLTAGE! LAST 20 MINUTES LISE COPPER CONDUCTORS ONLY GENERAL WIRING REQUIREMENTS AND PROVISIONS ACTUAL BASE LOADING SETPOINT USED IS SETABLE AT FRONT PANEL THE NO CONTACTS CLOSE ANYTIME THE CHILLER IS RUNNING IN ONE OF THE FOLLOWING MODES; ICE MAKING MODE OR CONDENSER PRESSURE LIMIT CONTROL MODE DISCONNECT ALL ELECTRIC POWER REFER TO IOM FOR DETAILS HEAD UNIT TERMINALS ARE NOT DESIGNED TO ACCEPT 6 THE EIGHT 1/2" CONDUIT KNOCKOUTS LOCATED NEAR THE TOP OF THE RIGHT HAND SIDE OF THE CONTROL PANEL ARE FOR USE WITH LOW VOLTAGE 30 VOLT CIRCUIT WIRING. PRESSURE RELIEF REQUEST OTHER TYPES OF CONDUCTORS INCLUDING REMOTE DISCONNECTS AND FOLLOW LOCK OUT AND TAG PROCEDURES FAILURE TO DO SO MAY CAUSE DAMAGE TO THE CONTACT RATINGS AND REQUIREMENTS CONTINUOUSLY FOR THE DURATION SPECIFIED BY THE CHILLER HEAD RELIEF RELAY FILTER TIME. BEFORE SERVICING, INSURE THAT ALL UNIT PROVIDED DRY CONTACTS FOR THE CONDENSER/CHILLED WATER PUMP CONTROL, THE UNIT OPERATING STATUS RELAYS AND ICE MAKING STATUS RELAY ARE RATED FOR 7.2 AMPS RESISTIVE, 2.88 AMPS PILOT DUTY, OR 1/3 HP, 7.2 FLA AT 120 VOLTS 60 HZ, CONTACTS ARE RATED FOR 5 AMPS GENERAL PURPOSE DUTY AT 240 VOLTS. MOTOR CAPACITORS HAVE DISCHARGED 7 THE SIX 1/2" CONDUIT KNOCKOUTS AND 4 1-1/4" KNOCKOUTS STORED VOLTAGE UNITS WITH VARIABLE **ATTENTION** LOCATED NEAR THE BOTTOM OF THE RIGHT HAND SIDE OF THE CONTROL PANEL ARE FOR USE WITH 115 VOLT CIRCUIT WIRING. SPEED DRIVE REFER TO DRIVE INSTRUCTIONS FOR CAPACITOR DISCHARGE WHEN ORDERED THE OUTDOOR AIR TEMP SENSOR ELECTRONICS IS FACTORY MOUNTED INSIDE THE CONTROL PANEL AND THE IPC BUS IS FACTORY WIRED. THE SENSOR IS TO BE FIELD WIRED, RELOCATED EXTERNALLY WITH THE SENSOR LEADS EXTENDED BACK TO THE CONTROL PANEL. THESE WIRES CAN BE SPLICED WITH TWO 14-18 AWS 600V WIRES, WITH A MAXIMUM LENGTH OF 1000 FT (305 METERS). SPLICE AT SENSOR END MUST BE WATER TIGHT. N'UTILISER QUE DES CONDUCTEURS EN CUIVRE FAILURE TO DO THE ABOVE BEFORE LES BORNES DE L'UNITÉ NE SONT PAS CONCUES SERVICING COULD RESULT IN DEATH OR POUR RECEVOIR D'AUTRES TYPES DE CONDUCTEURS CUSTOMER SUPPLIED CONTACTS FOR ALL CLASS 2 CONNECTIONS MUST BE SERIOUS INJURY. 8 CLASS I WIRING ,14 AWG, 600 VOLT CONDUCTORS. 115 VOLT CIRCUIT L'UTILISATION DE TOUT AUTRE CONDUCTEUR PEUT COMPATABLE WITH DRY CIRCUIT 24 VOLTS DC FOR A 12 MA RESISTIVE LOAD. SILVER OR GOLD PLATED CONTACTS ARE RECOMMENDED. ♠ AVERTISSEMENT ENDOMMAGER L'ÉQUIPEMENT 27 FLOW SWITCH & INTERLOCK CONTACTS MUST BE ACCEPTABLE FOR USE IN A 120 VOLT 1 mA CIRCUIT OR A 220 VOLT 2 mA CIRCUIT. **PRECAUCIÓN** TENSION DANGERFLISE! 10 TRANE TRACER SUMMIT RECOMMENDED WIRE: COUPER TOUTES LES TENSIONS ET ¡UTILICE ÚNICAMENTE CONDUCTORES DE COBRE! OUVRIR LES SECTIONNEURS À DISTANCE, PUIS SUIVRE LES PROCÉDURES DE VERROUILLAGE ET DES ÉTIQUETTES AVANT TRANE ICS SHIELDED TWISTED PAIR COMMUNICATION CABLE 14-18 AWG, 600V CABLE, 30 VOLT CIRCUIT. THE SUM TOTAL LENGTH OF 28 CHILLED / CONDENSER WATER PUMP STARTER AUXILIARY CONTACTS TO BE LAS TERMINALES DE LA UNIDAD NO ESTÁN DISEÑADAS PARA ACEPTAR OTROS TIPOS DE CONDUCTORES. RED IN SERIES WITH FLOW SWITCHES ALL INTERCONNECTED CABLE SEGMENTS NOT TO EXCEED 5000 FEET. GROUND THE SHIELD AT THE TRACER END ONLY. REFER TO THE IOM TOUTE INTERVENTION. VÉRIFIER QUE TOUS LES CONDENSATEURS DES MOTEURS SONT SI NO LO HACE, PUEDE OCASIONAR DAÑO AL EQUIPO FOR COMPLETE CABLE AND INSTALLATION REQUIREMENTS. SUMMIT MAY ALSO USE LCI WIRING RECOMMENDED BELOW. LONTALK COMMUNICATION INTERFACE (LCI) RECOMMENDED WIRE: 22 AWG LEVEL 4 UNSHIELDED COMMUNICATION WIRE RECOMMENDED 22 AWG LEVEL 4 UNSHIELDED LOUMMUNICATION WIRE RECOMMENTS
THE SUM TOTAL LENGTH OF ALL INTERCONNECTED CABLE SEGMENTS
NOT TO EXCEED 4500 FEET. CONNECTION TOPOLOGY SHOULD BE
DAISY CHAIN, REFER TO BUILDING AUTOMATION SYSTEM (BAS)
COMMUNICATION INSTALLATION LITERATURE FOR END OF LINE
TERMINITION RESISTOR REQUIREMENTS. DÉCHARGER LES CONDENSATEURS. NE PAS RESPECTER CES MESURES DE PRÉCAUTION PEUT ENTRAÎNER DES BLESSURES GRAVES POUVANT ÊTRE 19 CONDENSER CONTROL OUTPUT EXTERNAL BASE LOAD COMMAND
| 28 | ICE BUILDING CONTROL ENABLE | 24 | EXTERNAL BASELOAD SETPOINT INPUT (OPTIONAL) | 14 | (OPTIONAL) | 14 | (OPTIONAL) 14 COMPRESSOR % RLA OUTPUT (OPTIONAL) 14 MORTELLES. (OPTIONAL) 20 THE FIELD WIRING FOR THE 115V HOT LEG IS TERMINATED TO 1X6 ♠ ADVERTENCIA TERMINAL BLOCK, SEE INSTRUCTION LABEL IN CONTROL PANEL FOR 6 WIRE INSERTION INSTRUCTIONS. SPLICE FIELD WIRES TOGETHER AND IVOLTAJE PELIGROSO! WIRE TO 1X6. 9 DESCONECTE TODA LA ENERGÍA ELÉCTRICA, 30 \OUTDOOR AIR GENERAL NOTES TRANE TRACER SUMMIT CURRENT LIMIT SETPOINT CHILLED WATER SETPOINT AUTO STOP EMERGENCY STOP 26 26 10 LINK TO NEXT UNIT NCLUSO LAS DESCONEXIONES REMOTAS Y 12. CAUTION-DO NOT ENERGIZE THE UNIT UNTIL CHECK OUT AND STARTUP PROCEDURES HAVE BEEN COMPLETED. INPUT (OPTIONAL) SIGA LOS PROCEDIMIENTOS DE CIERRE Y 14 LONTALK COMM INTERFACE 14 (OPTIONAL) 14 ETIQUETADO ANTES DE PROCEDER AL NALOG INPUT (OPTIONAL) SERVICIO. ASEGÚRESE DE QUE TODOS LOS CAPACITORES DEL MOTOR HAYAN 13. COMPRESSOR MOTOR IS PROTECTED FROM PRIMARY SINGLE PHASE FAILURE DESCARGADO EL VOLTAJE ALMACENADO. PARA LAS UNIDADES CON EJE DE THESE FEATURES ARE OPTIONAL AND MAY OR MAY NOT BE PROVIDED DIRECCIÓN DE VELOCIDAD VARIABLE CUSTOMER PROVIDED WIRING FOR ALL STANDARD FEATURES AND OPTIONS CONSULTE LAS INSTRUCCIONES PARA LA DESCARGA DEL CONDENSADOR. IS SHOWN ON THIS DIAGRAM. OPTIONAL FEATURES ARE SO NOTED. EL NO REALIZAR LO ANTERIORMENTE CONDENSER WATER PUMP NDICADO PODRÍA OCASIONAR I A MUERTE O SERIAS LESIONES PERSONALES. OPERATING STATUS PROG. RELAY (OPTIONAL)

| OPERATING STATUS PROG. RELAY (OPTIONAL) | 14 OPERATING STATUS PROG. RELAY (OPTIONAL) | 14 OPERATING STATUS PROG. RELAY (OPTIONAL) | 29 (OPTIONAL) 11 AUXILIARY & FLOW 15. ALL FIELD WIRING MUST BE IN ACCORDANCE WITH THE NATIONAL ELECTRIC SWITCH INTERLOCKS CODE AND STATE AND LOCAL REQUIREMENTS. EXPORT UNIT WIRING MUST COMPLY WITH LOCAL APPLICABLE CODES. ALL UNIT POWER WIRING MUST BE COPPER CONDUCTORS ONLY AND HAVE A MINIMUM TEMPERATURE INSULATION RATING OF 75 DEGREE C. SEE UNIT NAMEPLATE FOR MINIMUM CIRCUIT AMPACITY AND MAXIMUM FUSE SIZE 7 22 22 22 22 8 REQUIREMENTS. USE 600 VOLT COPPER CONDUCTORS ONLY. 200 TO 600 25 CHILLED WATER PUMP AUXILIARY & FLOW SWITCH INTERLOCKS VOLT CIRCUIT, PROVIDE AN EQUIPMENT GROUND IN ACCORDANCE WITH CHILLED WATER PUMP STARTER BINARY OUTPUT ICE BUILDING STATUS (OPTIONAL) COND WATER PUMP STARTER APPLICABLE ELECTRIC CODES. 22 14 3 WIRES & GROUND IF REQUIRED BINARY OUTPUT 17 LINE VOLTAGE OPTIONS: UNIT MOUNTED TERMINAL BLOCK DISCONNECT OR HACR CIRCUIT BREAKER THE POWER WIRING LUG SIZE PROVIDED ON THE VARIOUS To use TABLE 1 select the RLA value from the unit nameplate. Go to one or more columns in the chart UNITS IS SHOWN IN TABLE 2. below and find a value that is equal to, or greater than, the RLA value. Read across to the left column and note the wire size, and across the top for the method, that is required for the installation. This table assumes a minimum circuit ampacity=1.25 (RLA) ALL CUSTOMER CONTROL CIRCUIT WIRING MUST BE COPPER CONDUCTORS ONLY AND HAVE A MINIMUM INSULATION RATING OF 300 VOLTS. EXCEPT AS NOTED ALL CUSTOMER WIRING CONNECTIONS ARE MADE TO NOTE: This procedure will offer several options for providing electrical service to the starter panel. Before making a final selection, review the accompanying TABLE 2 indicating wire ranges for the available lug sizes supplier on the equipment. CIRCUIT BOARD MOUNTED BOX LUGS WITH A WIRE RANGE OF 14 TO TABLE 2 POWER LUG SIZE (PER TABLE 1 SELECTION RLA PHASE CONNECTION LINE VOLTAGE (SEE NAMEDIATE) RECOMMENDED WIRE SELECTION TABLE (REF.2002 NEC) (2) #4 - 500 MCM RATED LOAD AMPS (RLA) 16 TERMINAL SUPPLY LEADS FOR ALL STARTER PANELS 599 - 779 NA 4 CONDUIT CLASS II 0 VAC MAX 6 (1) 3/0 - 350 MCM 201 - 476 (2) 2/0 - 500 MCM MAIN CIRCUIT CONTROL SECTION BREAKER (3) 3/0 - 500 MCM 120 140 240 280 641 - 779 (4) 3/0 - 500 MCM 192 224 252 294 384 448 360 420 480 560 28 28 OLTAGE ARE 7 8 (1) #1 - 600 MCM 8 294 326 365 368 408 456 184 204 228 386 428 479 589 653 730 NON-FUSED 278 - 397 (2) 2/0 - 500 MCM DISCONNECT 992 1072 1216 SWITCH (3) 3/0 - 500 MCM 599 - 779 (4) 3/0 - 500 MCM 3 582 \*\* Electrical conductors may be connected in paralled only for size 1/0 wire and larger per Nec 310-4 The unit nameplate will be marked 'Maximum Fuse or Circuit Breaker Size' The maximum fuse or circuit breaker size is calculated as follows: 3 581 Calculated value = 2.25 \* (Compressor RLA) The calculated value is then used to select the fuse or circuit breaker from the standard sizes mum Fuse or Circuit Breaker Size = The standard size that is closest to the calculated value without

G